

**Jet Thruster**

DOCK YOUR  
BOAT EASILY

Manufactured by  
Holland Marine Parts B.V.

**KEEP THIS MANUAL  
ONBOARD!**

# Installation manual & user guide

Jet Thruster Single & Combi

[www.jetthruster.com](http://www.jetthruster.com)



Jet Thrusters:  
JT-30 / JT-50 / JT-70 / JT-90

D-010-06


All our products are manufactured according to CE regulations.  
We keep the rights to change descriptions, graphs or statements,  
which are required for technical development of our Jet Thruster systems.




**HOLLAND  
MARINE PARTS**  
WE KEEP YOU MOVING!









## CONTROLLER UNIT: DIPSWITCH SETTINGS AND FLASHING CODES



## CONTROLLER UNIT: SINGLE & DUAL HELM SET UP




## CONTROLLER UNIT: SINGLE & DUAL REMOTE SET UP



# CONTROLLER UNIT: BOW AND STERN DOUBLE SYSTEM & REMOTE SET UP

## ATTENTION!

Both controllers dipswitch setting need to be on single.  
So pos 1 up all the rest down.  
Both valves need to be on valve one connection



# 1. Multifunctional Thruster Controller



E-307-00 Joystick extension cable  
- 10m / 33ft

(also suitable as optional second joystick connection cable)  
Use this cable if you need to extend the E-301-00 Controller to Joystick cable.



E-308-00 Pump unit extension cable  
- 5m / 16ft

Use this cable if you need to extend the Controller to Pump power cable.



E-309-00 3-way directional valve extension cable  
- 5m / 16ft

Use this cable if you need to extend the Controller to the Valve controller cable.

This controller is designed to control Jet Thrusters in single- and combi mode.

Also This controller can be used to operate Conventional thrusters of any brand, also in combination with a Jet Thruster.

This controller is designed to be used in pleasure crafts, to maneuver yachts sideways.

This controller comes with a two year factory guarantee.

## Content:

1. Introduction and Contents.
2. Installation and explanation of the Controller.
3. Program functions and settings, Led flashing codes.
4. Declaration of Conformity




## 2. Installation and Explanation


### Installation and Explanation

- The controller Should be mounted Vertically in an accessible location.
- Use Washers under the mounting screws to avoid damage and ensure a proper fixation.
- The controller is (if the provided caps are used) splashproof. (IP53)
- Ventilation is not necessary. operating temperature between 0°C (32°F) and 60°C (140°F)
- Power supply 12v DC (min. 10volt max. 20 volt) DO NOT EXTEND THE POWER CORD. OBSERVE POLARITY RED = +12V BLACK = NEGATIVE/ GROUND - **Never use the thrusterbatteries to power the controller, instead use the servicebatteries**
- All cables connected to the controller should: 1. Have adequate tension relief mounted. 2. Not go together in a bundle with 220v/110v cabling. (min. 10 cm (4") distance) 3. Not go together in a bundle with VHF antenna cables. (min. 10 cm(4") distance) 4. Be passed through Carefully to avoid damaging the cables

### Connection order



### Behind the caps you'll find:



- The power led lights if there is a 12v DC power supplied. If the fuse is broken this Led will not light.
- The status led provides the same information as on the joystickpanel. (see next page Flashing codes)
- The Dipswitches allow you to set up the controller for your application. (see next page )
- The Invert switches allow you to invert the valve or thruster operation.

### 3. Program Functions and Settings

behind the Left cap you'll find the dipswitches, Control Led's and Invertswitches.  
Below their function is described.

Dipswitches ((Firmware V04.001) dd 20-11-2018)

*On is Up and Down is Off. (Between brackets is standard setting.)*

- 1- Single (on) or Combi (off) (on)
  - 2- Conventional Bow thruster. (on) Jethruster (off) (off)
  - 3- Conventional stern thruster. (on) Jethruster (off) (off)
  - 4- Future use (off)
  - 5- Future use (off)
  - 6- Future use (off)
  - 7- Latching on/off (in case you don't want to use the pushbutton)\* (off)
  - 8- disable power off timer (off)
- \*you can either use a latching switch or connect blue to brown ,to use the power supply on/off function.  
(example: ign. switch) Never connect +12v to the control wires.*

*\*you can either use a latching switch or connect blue to brown ,to use the power supply on/off function.(example: ign. switch) Never connect +12v to the control wires.*

*In Case of electromechanical disturbance or static discharge the controller will shut down.  
Push the button again to re-start the system.*

#### Flashing Codes

- |                                      |                                                                                                                                                   |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| - Green Led is off                   | - No Power or defective Fuse.                                                                                                                     |
| - Green Led is on                    | - power present Controller is on and standby.                                                                                                     |
| - Red Led is off                     | - Controller is standby. ( automatically after 10 minutes)                                                                                        |
| - Red Led is on                      | - Controller is on and OK.                                                                                                                        |
| - Red Led Flashing fast              | - Engine overheated, (Let Cool Down, Auto reset)                                                                                                  |
| - Red Led Flashing code V<br>• • • — | - If system has never run, you need to create common ground ( <a href="#">see page 12</a> )                                                       |
|                                      | - Valve not open or closed in time. (turn system off/on.<br>If malfunction remains, one of the valves is stuck.<br>(Valve can be cleaned easely.) |

If upon installation the red led is flashing fast, make sure the Negative of battery 1 (and pump) is connected to the ships ground or the negative post of the battery powering the controller.

#### Invert switches

Using these switches You can invert the valve- or thrusteroperation, this simplifies installation.  
the left switch is for the stern and the right for the bow.



**Warning:** A wrong setting can cause damage or Injury!!

Keep your face and hands on a safe distance from thrusteropenings !!



## Electrical Installation: Jet Thruster Single and Combi

Holland Marine Parts recommends Optima Batteries

**OPTIMA**™  
**BATTERIES**  
THE ULTIMATE POWER SOURCE™



Optima battery YT S 5.5L


JT-30 12V	1 x YT S 5.5L 75Ah
JT-50 24V	2 x YT S 5.5L 75Ah
JT-70 24V	4 x YT S 5.5L 75Ah
JT-90 24V	4 x YT S 5.5L 75Ah

Visit our website  
[www.jethruster.com](http://www.jethruster.com)  
for additional information.

**!** If you decide not to use Optima Batteries: Apply batteries with at least 1000A CCA (Cold Cranking Amps.)

## Red flashing code fast - During first Test Run

If the controller indicated no Common ground there will be a Green light on and Red Flashing fast. Please follow this schedule to resolve this problem.



## Jet Thruster pump units



### JT-30 compact 66 thrust LBS 12V

Force	30 Kgf
Voltage DC	12V
E-motor capacity kW	3kW
Current	480A
Master fuse	500A
Recommended battery capacity 12V	1 x Optima Yellow Top 55Ah
Battery cable +/-	1m -> 50mm <sup>2</sup> / 3ft -> 1/0 AWG
Water inlet	1 x Ø 90 mm
Water outlet	Nozzle Ø 36mm/1,26"
Pressure hose diameter	2" / 51 mm
Weight pump	19kg/42LBS



### JT-50 compact 110 thrust LBS 24V

Force	50 Kgf
Voltage DC	24V
E-motor capacity kW	6kW
Current	480A
Master fuse	500A
Recommended battery capacity 12V	2 x Optima Yellow Top 75Ah
Battery cable +/-	1m -> 50mm <sup>2</sup> / 3ft -> 1/0 AWG
Water inlet	1 x Ø 90 mm
Water outlet	Nozzle Ø 36mm/1,26"
Pressure hose diameter	2" / 51 mm
Weight pump	25 kg/55 LBS



### JT-70 154 thrust LBS 24V

Force	70 Kgf
Voltage DC	24V
E-motor capacity kW	11kW
Current	800A
Master fuse	1000A (2x 500A)
Recommended battery capacity 12V	4 x Optima Yellow Top 75Ah
Battery cable +/-	1m -> 70mm <sup>2</sup> / 3ft -> 3/0 AWG
Water inlet	1 x Ø 4"
Water outlet	Nozzle Ø 50mm
Pressure hose diameter	3" / 76 mm
Weight pump	49 kg/95 LBS



### JT-90 198 thrust LBS 24V

Force	90 Kgf
Voltage DC	24V
E-motor capacity kW	15,5kW
Current	1000A
Master fuse	1000A (2x 500A)
Recommended battery capacity 12V	4 x Optima Yellow Top 75Ah
Battery cable +/-	1m -> 95mm <sup>2</sup> / 3ft -> 4/0 AWG
Water inlet	1 x Ø 4"
Water outlet	Nozzle Ø 50mm
Pressure hose diameter	3" / 76 mm
Weight pump	61 kg/130 LBS

Installation manual with product specifications at:

[www.hollandmarineparts.nl/download](http://www.hollandmarineparts.nl/download)





*The electric motor of the Jet Thruster generates a lot of power in a short period of time. It is necessary to connect dedicated batteries to the system. It is necessary to make the connection between this battery and the system as short as possible. Use appropriate battery cables and connecting material for this at all times. The system must be equipped with the included main fuse, which must be installed in the battery positive cable. For safety reasons, the Jet Thruster should be provided with a suitable main switch (not included).*

**The joystick operates on 12V. For vessels with a 24V installation, a DC-DC converter must be applied.**

**Please note:** Place batteries directly next to the pump unit.

Keep battery cables as short as possible to avoid voltage drop and loss of energy.

**Please note:** For a 12 Volts ship's circuit you need to install a series-parallel switch to be able to charge the system on 12V and use it on 24V. The JT-50, JT-70 and JT-90 come with a connection wire **F and G** as a standard accessory for this switch.

**Recommended battery cabling:** (at a total length of max. 1m/3ft)!

JT-30 (12V) 50 mm<sup>2</sup> (1/0 AWG) for 1m/3ft

JT-50 (24V) 50 mm<sup>2</sup> (1/0 AWG) for 1m/3ft

JT-70 (24V) 70 mm<sup>2</sup> (2/0 AWG) for 1m/3ft

JT-90 (24V) 95 mm<sup>2</sup> (3/0 AWG) for 1m/3ft

**Positive cable total length max. 50cm./1.64 ft**

**Negative cable total length max. 50cm./1.64 ft**



**To avoid long cable length:  
Batteries must be placed directly next to pump unit!**




*For optimum performance keep battery cables as short as possible!!*

#### **Charging the batteries:**


In order to keep the ship's circuit separate from the Jet Thruster battery/batteries it is recommended to divide the charging current with a diode bridge or MosFet battery separator from the alternator.

**Please note:** More electricity will be required as a result of the installation of the Jet Thruster. That is why in some cases it is recommended for the alternator to be converted to high yield or to place a separate alternator.


## JT-30 (12V) charged with 12V charger




## JT-50 (24V) charged with 12V charger



## JT-50 (24V) charged with 12V Step up Charger




## JT-70/JT-90 (24V) charged with 12V charger







## JT-70/JT-90 (24V) charged with 12V Step up




## JT-70/JT-90 (24V) in a 24V board network




## JT-70/JT-90 (48V) in a 24V board network



## JT-70/JT-90 (48V) in a 12V board network



## JT-50/JT-70/JT-90 (48V) in combination with electric propulsion




## Series - parallel switch

The Series Parallel Switch creates a temporary 24V environment out of two 12V batteries to power the DC motor from the pump unit.

**The switch itself operates at 12V.** The moment the Jet Thruster system activates, 12V power activates the coil that makes the switch connects the battery cables. Automatically the connection will break if the Jet Thruster stops running.

### E-135-00 (1m)

This cable is on one side pre mounted on the contactor. You only need to connect the free side to the series parallel switch. It does not matter which way you connect it!




## Installing the electrical air valve

### Operation:

The pump head of the Jet Thruster system must be installed under the water line in order to prime this centrifugal pump. In some limited cases of fast moving vessels a vacuum can be produced when the nozzles rise above the waterline and the intake remains in the water. The suction under the fast moving hull will retract the present water from the Jet Thruster system. When the boat slows down or stops the water will automatically flow into the system due to the fact that the pump head and nozzles are under the waterline.


However, it is possible that an air pocket can be trapped in the pump head preventing the pump from self priming. In this unique situation an Electrical Air valve can be installed, this will release the present air from the pump head allowing the pump to rapidly prime. Giving the operator immediate thrust pressure for maneuvering.




### How to install the Electrical Air Valve:

- A. Remove the winterization plug located on the pump outlet fitting. Ⓐ
- B. Install the provided  $\frac{1}{8}$  hose connector.
- C. Make sure to install the Electrical Air Valve above the waterline!**
- D. Apply the supplied flexible hose and hose clamps between the pump unit and Electrical Air Valve.
- E. Apply the supplied flexible hose from the Air valve to outside of the vessel. In case of a technical failure, water that comes from the pump unit when the Jet Thruster system is engaged, will be pumped outside the vessel.

Follow diagram complete the electrical installation.







## Torque on battery cable connections and other parts




**Warning:** Loose or insufficient tightened battery connections can cause damage or fire:

Make sure to tighten the nuts of the connections as mentioned.


Use quality terminals and right crimping tools to ensure a quality electrical installation safety!

Battery cable terminals contactor SW-200

M10 main terminals to be tightened within the range  
13.4 to 14.6 Nm



Fuse holder: torque 15Nm to nuts.




Single fuse holder

Double fuse holder

Pump outlet

Torque max. 9Nm



**Note:** Over tightening will press out the seal  
and damage the pump head!

Hose clamps

48-60mm



I-114-00, 40 Nm

77-94mm



I-331-00, 45 Nm

60-76mm



I-116-00, 40 Nm

---

## Warranty provisions

On all its newly manufactured products Holland Marine Parts provides quality assurance regarding their proper operation, both with regard to the material and the work done, including latent defects, for a period of 24 months after the invoice date to the first receiver.

In case of defects in material and/or defects caused by inadequate work done, as covered under warranty by Holland Marine Parts, the relevant part or the whole device will be either repaired or replaced at the discretion Holland Marine Parts, free of charge.

The warranty periods specified in the first paragraph are not extended by the implementation of repairs under warranty.

Any costs associated with travel, transportation and installation and/or disassembly with regard to repairs covered under warranty will be borne by the owner of that device.

Damage to the product caused by improper installation, by intentional or unintentional misuse, lack of maintenance, normal wear and/or repair by third parties without the written permission of Holland Marine Parts are not covered by warranty.

Holland Marine Parts shall under no circumstances be liable for any consequential damages of any nature whatsoever or howsoever caused by the part or the whole product covered by warranty by Holland Marine Parts.

Please note: Exclusion of warranty: The pump head of the pump unit and the seals on the 3-way valve are tested to be water-proof. If they are opened/removed/damaged this will void all liability towards Holland Marine Parts in the occurrence of damage as a result of these actions.



This is the safety alert symbol. It is used to alert you to potential hazards. Obey all safety messages that follow this symbol to avoid possible injury, damage. This Installation Manual and User Guide provides advice and instructions towards the mechanical and electrical installation of the Jet Thruster system. Remember: Always use common sense when installing, using and servicing the Jet Thruster and its components. In case anything is not clear: Contact your dealer or Holland Marine Parts BV for assistance.

In this manual the installation of the JT-30, JT-50, JT-70 and JT-90 in Single and Combi setup is explained. Choose the installation procedure that applies to the system you have purchased.



Damage to system components due to Galvanic corrosion, Electrochemical corrosion and Stray current corrosion are excluded from warranty. Install cathodic protection as advised in this manual.

# Before you start:



watch our installation video's!

[www.youtube.com/user/hollandmarineparts](http://www.youtube.com/user/hollandmarineparts)

---

## Jet Thruster installation

### Important information before you start

A Jet Thruster is a Battery powered water pump system which pumps water from A to B: The water intake and water exit can be at different locations in a boat, which is unique for bow or stern thruster systems for pleasure boats. It will open technical solutions for boats which have problems to fit a thruster.

The key components of the system are: Water intake, Pump unit, Directional Valve and the nozzles. Compared to other thruster systems a Jet Thruster is much more flexible to install. Nozzles are placed just below the waterline, which is a great benefit compared to propeller thrusters: The position of the nozzle below or above the water line, does not affect the function. In case the boat is rolling or heaving, and the nozzles rise above the waterline, the Jet Thruster will be 100% effective. For boats with shallow draft at bow or/and stern, this system is very interesting: Because the nozzles can be placed just below the water line, they can be placed, maximum forward and aft, at a maximum distance from the pivoting point. A larger “arm” of momentum towards the pivoting point, results in a increased effectiveness/performance.

**So this is your goal: To have the nozzles at a maximum distance from the boat’s pivoting point.**

Important instructions must be taken into account. Further on you will find installation recommendations. Contact your Distributor/dealer in case you have additional questions, or contact Holland Marine Parts. Always make sure to fully read the installation manual which is provided with each Jet Thruster system



Dufour 460 Grand Large

---

## Make a basic installation plan: 4 important sections

### 1: Optimum pump position and water inlet

- The Jet Thruster Pump unit must always be placed below waterline.  
The position in the boat is not important, as long as the pump is below the water line!
- Selection of the pump head outlet position: 2 possible positions
- Keep hose length as short as possible
- Place the batteries directly next to the pump
- Check location of water inlet: Maximum 1 meter hose for inlet to pump

### 2: Position of Directional 3-way valve

It is preferred to have the directional 3-way valve as close to the nozzles as possible, to eliminate long hose length, position of valve can be above or below water line. The valve can be placed upside-down or in a sideways position, as long as the valve house body is thoroughly connected to the hull or interior/carpeting. The valve can be glued in place with PU sealant, or fixed with the 2 recesses at the valve body. Do not let the valve rest on the plastic cover.

### 3: Position of Nozzles (Bow and Stern)

The Jet Thruster will be most effective when the nozzles are placed as far forward or aft as possible. The topside of the nozzle tube must be 7-10cm below the waterline, not deeper or higher. In case of a narrow bow, you can cross the hoses. Each nozzle has a 2" Ball valve.

### 4: Electrical installation

See dedicated chapter in this manual.



---

## Preparations: Connecting Stainless steel parts with Sikaflex291i

You are going to work with Stainless steel parts. Do not use iron tool to stainless steel surfaces which come in contact with (sea)water. If you do this, later on this will possibly cause corrosion to the stainless steel parts.

The threads from all connections must be thoroughly cleaned with acetone to remove grease from the threads.


We often receive questions about the connection of stainless steel parts. The preferred method is to use a Poly-Urethane sealant. A well know product to the Maritime Industry is Sikaflex291i: A high quality component Poly-Urethane sealant, available in black an white. We recommend to use white Sikaflex 291i.

Sikaflex291i must be applied to the threads you want to connect. Use a sufficient amount of this product and spread out to the entire thread of both male and female parts. When you assamble the parts into each other, you will feel the resistance of the adhesive. For the larger parts such as the hose connectors, it takes some muscle power before you have all parts in place. Now something interesting follows: Jet Thruster components work with BSP threaded parts, not NPT. The means you do not have to continue until the parts jam. When you have the parts in position, check for alignment with the other parts. You will have 15 minutes in which you are able to make correction. After the Sikaflex 291i starts curing, do not move the parts anymore. After 24 hours, a very strong, reliable and water tight connection is established. Sikaflex291i will bond stainless steel parts very well.

You can use Industrial wipes to remove excessive Sikaflex 291i adhesive or clean stains from the parts. Do not use Teflon tape or other sealants: The best results to connect stainless steel parts will be when you are using Sikaflex291i.

### Dry-fitting of the Stainless Steel parts:

It is preferred to dry-fit and mark all parts before you drill the holes. Dry-fitting is part of the installation plan. Be careful when dry fitting: do not damage any part of the threads from stainless steel components. Do not jam stainless steel to stainless steel parts. They will get stuck very easy. Be careful with the parts and threads when processing the parts. A damaged thread can give you a hard time...



*JT90 Combi pump unit*

### 1: Pump, pump position and water inlet

A Jet Thruster makes use of a dedicated, not-self-priming, centrifugal pump. You must place the pump below the water line for this reason. More specific: At least the top side of the pump head must be below the water line. This means you need to be at least 30cm below the water line, for the position at which you are planning to place the pump. When the pump is below the water line, there will be a natural positive pressure to the water-inlet side of the pump. Automatically the pump will prime.

Pressure hoses from the pump to the valve and nozzles can be installed above the water line. If it is cold: heat the hoses with a paint-remover (not too hot!) Warm hoses are much more flexible and easier to install.

You can place the pump any where in the boat as long as you keep the pump below the water line. You have to keep the water inlet close to the pump. Similar to cooling water for the main engine, the Jet Thruster system has a thru-hull connection. On the outside there is a filter, so no plastics or rope can come into the pump. On the inside of the boat, there is a ball valve to open and close the water supply to the pump.

The inlet hose for the pump has a maximum length of 1 meter. If the standard provided 90-degree elbow is difficult to install, you can change this for 2x 45-degree elbows. Check out our catalog, We explain every combination, and show the alternative parts. Each installation is a custom project. The Jet Thruster is very flexible system to place. You can select alternative components from our catalog in case there are problems to install the standard parts.

You can place the pump head in 2 different positions: Horizontal outlet, or vertical outlet. A straight, and 90-degree pump outlet are available. It's quite easy to change the pump head position. Ask Holland Marine Parts for instructions. Read the installation manual: For each pump, all sizes and dimensions are published. Upon request AutoCAD/3D files for each part of the Jet Thruster systems are available.

Make sure to keep space free behind the motor. At least 15 centimeter. Remember that you must be able to remove the plastic cover for the electrical controls

With Sikaflex 291i you can directly glue the pump in place. The Sikaflex291i provides a ultra strong connection. Clean hull and the pump bracket with acetone, and use sufficient Sikaflex291i. If the position is not horizontal the pump will try to slide away. Fix the pump in place during the curing process of the adhesive. After the Sikaflex291i is cured, the pump is connected very well to the hull. You can always remove the system by unbolting it from the bracket.

You can laminate a wooden plate to the hull, in that case, you can bolt/fix the pump into position. All pump brackets come with recesses for this purpose.

After you have determined a preferred place for the pump, the next step is to check the Water inlet position. Pump and inlet assembly will be close together in every circumstance:

Be creative: You can drill a hole thru a wall or storage if you want to place the inlet assembly in a different position. It's possible to bend the 1 meter inlet hose. The water inlet assembly often does not align horizontal with the pump inlet connection. Instead of a single 90 degree elbow you can order 2x 45 degree elbows for the inlet assembly. This will enable more flexibility towards the position of all components

Always make sure to place the batteries directly next to the pump unit. Keep space available, and make sure this does not affect the balance of the boat.

## Water inlet assembly

The following parts are part of the Water inlet assembly:

- Water inlet (3" or 4" depending on your system)
- Nut 3" or 4"
- Elbow 90-degree
- Ball valve
- Hose connector
- Hose (1 meter) or optional bellow



*Water inlet filter*



The water inlet must be close to the pump. The inlet is protected with a filter. Make use of the tool, provided with the water inlet to have grip/control during installation. After you drilled the hole, make sure to remove anti fouling until you reach the gelcoat. You can mark the exact outside diameter of the flange from the inlet by carving around the flange with a knife. With precision you now are able to exactly see how much antifouling or paint you have to remove.

Thoroughly clean the hull and the stainless steel parts with acetone. Use sufficient Sikaflex291i. Use the tool to screw the water inlet into 90 degree elbow. For this we developed a method. See below.

It is important to keep sufficient space between the hose connection of the pump and the hose connector of the water inlet assembly. A little vibration of the pump must be absorbed by the hose. If you have no space, you can choose to apply a bellow which we have available when you have to connect the hose connectors directly to each other. A bellow will ensure a flexible connection between the pump and the water inlet assembly.

It's possible to drill and install all parts without paint repair or necessary to fiber glass, which makes the installation go faster and less expensive

## Water inlet installation checklist:

*Tool for grip on water inlet*

2 persons required for this process:  
one person inside, and one outside the boat



- Drill the hole, make sure to dry-fit the water inlet so everything will fit perfectly
- Remove antifouling below the flange
- Clean/degrease hull and parts
- Clean threads and prepare the 90 degree elbow inside the boat
- Press water inlet into the hull
- Place the nut on the inlet and screw this a few centimeters on the threads
- Apply Sikaflex291i to the top 3 cm. threads of the water intake
- Apply Sikaflex291i to the female threads of the 90 degree elbow
- Apply Sikaflex291i to the flange (outside the boat)
- Use the provided tool and a wrench with a long arm: 30-40cm and slowly turn the inlet. Keep the 90 degree elbow in place and connect it with the water intake, keep turning until the water inlet is connected well with the 90 degree elbow.
- Make sure enough Sikaflex 291i is present. During turning of the inlet, some Sikaflex291i will be pressed out. You now have to make sure enough Sikaflex291i is present for the last step:
- Press the inlet towards the hull. Inside the boat the nut must be tightened thoroughly
- Remove all spilled Sikaflex291i with the industrial wipes
- Continue with placing the other parts of the water inlet assembly
- Very important: Before the Sikaflex291i will start to cure: Immediately check alignment with pump inlet: Now is the time to make small corrections to the 90 degree elbow if necessary
- After 15 minutes, depending on temperature / humidity etc do not move the parts anymore.

---

## Directional 3-way valve:

There are 2 different directional 3-way valves: Jet Thruster Single and Jet Thruster Combi valves. The difference between them is the electrical operation. Jet Thruster Combi valves are equipped with a control box and 10m/33ft meter cable is included.

The valve itself is made from casted Stainless steel. Hose connectors are already casted on to the valve, so you can directly slide hoses over the connections. Make sure to tighten the provided 2-shell clamps very well. Use electrical wrench to maximum tighten the clamps.

The valve can be placed anywhere. Even on the side or upside down. make sure to make a drain hole in the plastic cover in that case. The valve does not necessarily has to be installed below the water line. This makes it easier to find the right place. For a nice installation with less hose, we recommend to place the valve close to the nozzle, but if necessary you can place the valve anywhere in your installation.

The valve is equipped with electrical components. Choose a dry, ventilated position for the 3-way Valve.

Similar to the pump, you can use Sikaflex 291i to directly fix the valve with the valve housing to the hull or interior of the boat. Make sure our are always able to place/remove the plastic cover. Do not open the valve. Do not lift the valve by the cover or by the cable, it is not designed for that.

**Jet Thruster Single:** Remove the black plastic cover, by unscrewing the 3 screws. Below the cover you will find the terminals CDE for electrical connection.

**Jet Thruster Combi:** Cut the neoprene cable to required length and connect with the terminal connections at the pump unit.

Do not worry about the side to which the water will exit later on. After you finished the installation and the boat is back in the water, the direction can be switch at the joystick panel. So without a problem you can cross the hoses if this is required for the installation.

## Cutting the flexible rubber hose

Rubber reinforced hoses are used to transport water thru the Jet Thruster systems. These hoses are tough: Multiple layers of, rubber, canvas and metal wire make the hose can withstand high flow pressure.

A Jet Thruster is all about flow, (not pressure, the pressure inside the system is not more than 2.5 bar)



*Crossed hoses*

Cutting the hose is done with a sharp knife. Slightly bend the hose, while making a carve or cut into the material. Do not use a lot of force. Bending and cutting does the trick. At some point, metal wires will be exposed. These can be cut with a set of pliers. Cut back the wire into the rubber to hide the sharp edges. Exposed wire ends after cutting are very sharp. Pay attention here.

Do not use a saw, or disc cutters to cut the hoses. Use a sharp utility knife.

When it's cold, it is preferred to heat the rubber compound with a heat gun on the inside of the hose for 15 minutes.

---

A Heat Gun with variable temperature enables you to soften the rubber compound of the hose. If cold the hose is quite stiff and difficult to process into the installation. Especially when you have to make bends, it's preferred to heat the rubber, and bend it whilst being warm.

## Hose Clamps

The special selected hose clamps are very strong. We recommend the use of power tools to tighten the nuts of the clamps. Power tools such as a Impact Wrench enable you to maximum tighten the clamps.

Start with adding some grease to the thread of the bolt. Impact Wrenches apply a great amount of power to the nuts, a little bit of lubrication to the tread is preferred.



Use a Long-Reach Impact Socket as the threads of the bolts are quite long.

Make sure both shells and the 2 smaller parts slide into each other correctly. Bring a small flashlight, to see if the parts fit in place prior to tightening them. Obviously the clamp must be over the hose in the middle of the hose connector, so the shells will firmly in place.

Torque; I-331-00 45Nm and I-114-00 40Nm

## Nozzles:

Nozzle position for the Jet Thruster system is very important. It is beneficial for the overall performance of the system to have the nozzles maximum forward, or aft in the boat. A longer arm of momentum towards the pivoting point, will increase the overall performance of the system.

We strongly recommend you to visit YouTube and watch the installation videos:



Search our for channel: Among the video's you will be able to find several installation video's: Search for: **Jet Thruster installation Video: JT50 Bow Dufour 36 Classic:** This video provides detailed information.

Because each installation is different, we created 4 golden rules, so it is easy to find the best nozzle position. If your boat comes out of the water, do not clean it yet! Now in this situation the waterline is visible very well. It will give you a perfect reference where to place the nozzle. Jet Thruster nozzles are very small. Much smaller compared to traditional tunnel thrusters, and because they only have to be 7-10cm below the water line, you can place them much more forward. If there is a water tank or any other obstacle which cannot be removed, possible you can place the valve in front of the tank, and run the hoses above, over or even below the tank. Use your technical creativity! Each centimeter you place the nozzles more forward to the bow, you will increase the efficiency and power of the system.

Basically the nozzle is a normal thru hull connection. Because in most cases the bow is under a angle we have 6 different nozzle angles available. With these 6 angles, it's possible for almost any boat to install the system correctly. You can use the folding tool, present in our catalog to determine the right angle, or look at our installation video's at Youtube.

---

## Golden rules: Just do this step by step:

- Place the nozzle maximum forward or aft, take into account that you have to connect the 45-degree elbows and ball valves on the inside of the boat
- Top side of nozzle tube (not the flange) 7-10cm below the water line
- Keep nozzle tube horizontal
- Keep nozzle tube in 90 degree to the center line of the boat.

You can hold the nozzle to the outside of the hull and rotate the flange 180 degrees to see if the nozzle tube is horizontal. When the water line is still visible on the boat, it's now very easy to find the right place.

If you place the nozzles too high, the system will still work at 100% but you will see a lot of water spray.

If you place the nozzle deep, you probably are placing them backwards towards the pivoting point and reduce the effectiveness of the system. When you place them deep you do not see any turbulence in the water. If you want some action of the water, keep the nozzles 7-10cm below the waterline. If you prefer a ultra silent system, placing them a bit deeper will result in a silent operation.

For the stern of sailboats we have a 55 and 65 degree nozzle. The flange of this nozzle is already curved to follow the hull. Often for sailboats with shallow draft the nozzles will be above the just below the waterline. This is no problem. The system will work 100% above or below the water line, it's a jet! But: to avoid a lot of water spray and sound, it is better to keep them below the water line. For boats which are deep enough in the water, we have the 90 degree transom nozzles. A perfect nozzle to attached to the stern of the boat. You can use the 0-degree nozzle to place these in the sides of the boat. Because the pump can be in a different place, you can guide the hoses thru the boat, towards the valve, and the pump. A Jet Thruster is a Very flexible and efficient stern thruster.

For steel and aluminum boats special nozzles are available. This is a nozzle type without a flange. After drilling the hole, this nozzle will be inserted in the hole and welded into position on the outside and inside of the hull. Afterwards you can trim of the part which is on the outside, and smoothen the hull. The JT30 and JT50 have a plastic Venturi present inside the tube. Remove the venturi prior to welding the nozzle in place. The heat will damage this element. After welding, the venturi can be fixed in place with Sikaflex 291i.

## Installation preparations for flange threaded nozzles:


After you determined the optimum position for the nozzle, it's time to drill the holes.

It's not necessary to have the nozzles directly opposite to each other. You can place one of them a bit more forward than the other. This will make the installation more compact, and you are able to place them more forward into the hull. Due to this shifted nozzle position, there is more space to connect the parts. You can cross the hoses. Make sure you thoroughly clean all threaded connections with acetone. This is very important.

---

**A Jet Thruster nozzle assembly includes the following components:**

- Nozzle
- PVC Spacer
- Nylon washer
- 2" nut
- 45 degree elbow (if you do not need it, do not use it)
- 2" ball valve
- 2" Hose connector



**Drilling process:**

**Possible you are not able to drill in one stage. We recommend a multi stage drilling process:**

- Drill a pilot hole for your hole saw center drill
- Use a 60mm hole saw, use the longest drill you can find. This is more easy
- Use a long center drill
- Keep your drill horizontal at all times
- The top of the drill will make contact first, keep drilling until you are at 1/3
- Use tools to cut out the top side of the debris
- Make sure the hole for the center drill remains in tact
- Continue drilling until you are at 2/3
- Remove debris
- Topside of the hole now will guide your hole saw, as the centerdrill is not supported
- Smoothen edges on the inside and outside
- Clean and thoroughly sand the edges which will be below the flange.



Don't worry if pieces of the gelcoat at the edges crack or blister. Later on the flange of the nozzle will cover and hide this.

**In some cases boats are built with a in and outside shell structure.**

The nozzle will fix to the outside shell. A larger hole must be cut to the inside shell to make place for the PVC spacer. Possible you have to cut away foam or other material present between the shells.





---

## Important Preparation advice:

Possible the best thing you can do is to cut all hoses to the required length before you start the Nozzle parts assembly with Sikaflex291i:


- Make sure the directional 3-way valve is fixed firmly into position
- Cut hoses to required length / test fit them
- Slowly heat up cold hoses with a heat gun. Have a heat gun blow hot air in the hose for aprox. 15 minutes until the hose is warm and flexible.

## Installation process of the nozzles:

- After you thoroughly cleaned the parts, two persons are needed to install the nozzles.
- Sufficient Sikaflex291i must be applied to the backside of the nozzle flange.
- One person, present outside the boat must press the nozzle in place from the outside in.
- Place the PVC spacer
- Place Nylon washer
- Place 2" Stainless steel nut
- Firmly tighten the nut. Check if nozzle tube remains horizontal.
- Remove excessive Sikaflex291i with use of Industrial wipes
- Continue with the other parts of the nozzle assembly.

Now when you have all the parts of one side of the boat in place, and your Sikaflex will soon cure, it's a perfect moment to attach the heated and prepared hose to the hose connector of the nozzle assembly. In addition the other end is connected the hose connector of the 3-way valve.

Stress inside the hose will be released towards the nozzle assembly. Because the Sikaflex291i has not cured, the parts will set in the perfect position. After the hose cools, and the Sikaflex291i is cured, connections are free of stress.



## Frequently asked questions



Q: Can I use the system for propulsion?

Q: Can I use the main engine to drive the Jet Thruster pump unit?

Q: How are SS316 BSP threaded parts of the system connected?

Q: Can I use Teflon tape, Hemp-fibre or any other product for connection of SS316 parts?

Q: I dry-fitted SS316 parts, but now they are stuck, what can I do?

Q: Can I use 90 degree elbows?

Q: Can I cut off a piece of the nozzle?

Q: Which boats can have a Jet Thruster fitted?

Q: How do I determine which system is suitable for my boat?

Q: I have a wooden boat, can I install a Jet Thruster?

Q: I have a Aluminium hull, can I install a Jet Thruster?

Q: I have a Aluminium hull, can I install a Jet Thruster?



A: The Jet Thruster system has been designed for manoeuvring, not propulsion.

A: Theoretically this is possible but not engineered by Holland Marine Parts towards the connection components.

A: All connections must be made with a PU Sealant such as Sikaflex 291i. PU sealant will bond the parts extremely well.

A: No, this is not recommended, the best connection will be achieved with a PU-Sealant.

A: Avoid parts getting stuck. SS316 parts which are dry-drifted and jam at the end of the threads will be very difficult to separate. Check parts for burr's or damaged threads prior to dry-fitting them.

A: Preferably not, they will reduce the efficiency of the system. If you need to make a 90 degree curve at a narrow bow section curve, use two 45 degree elbows with the 2" ball valve between the elbows to ensure a good flow.

A: Yes, as long as the plastic venturi (present at JT30 and JT50 is not damaged.)

A: Any boat for which 30 up to 90Kgf thrust force will be sufficient.

A: It's important to calculate the wind catch of the boat. Use the App and information at our website to find out how much thrust your boat needs to turn it into the wind. Our App makes suggestions based upon the wind catch of your boat.

A: Yes you can, in fact, due to the very small hull penetration, a Jet Thruster is a perfect product for boats with a wooden hull. No need to fiber-glass a tunnel anymore. In fact, A Jet Thruster system is suitable for any type of material made for making hulls.

A: Yes, for Aluminium hull's a dedicated installation kit is available including Aluminium thru-hull parts (need to be welded in).

A: Yes, for Aluminium hull's a dedicated installation kit is available including Aluminium thru-hull parts (need to be welded in).





Q: I already have a bow thruster, can I connect the existing bow thruster to a control panel of Holland Marine Parts?

Q: Are there possibilities for a dual helm-setup of the controls?

Q: Can I use my existing batteries to power the Jet Thruster?

Q: My boat has a 12v system, can I install the 24V powered Jet Thruster system?

Q: How deep below the waterline must a nozzle be installed in order to be effective?

Q: Where do I need to place the Jet Thruster pump?

Q: Where do I place the thru-hull water inlet part?

Q: How long can the flexible hoses be?

Q: Does a Jet Thruster compare in power to tunnel thrusters?



A: Instead of a panel with one joystick, we can provide a panel with two joysticks. Jet Thruster for the stern, and existing bow thruster can be operated from one panel.

A: Yes, the uncomplicated electrical controls enable multiple helm setups or connection to third-party products

A: No, you need to install a dedicated set of Optima Yellow Top batteries in order to achieve the maximum efficiency of the system.

A: Yes, for this purpose we sell a product called Series-Parallel Switch. This device is engaged by the control circuit, and will switch the dedicated 12V Jet Thruster batteries from Parallel temporary into series. Two, (or 2 sets) of 12V charged batteries will deliver 24V when switched into series. This switch is self-acting in control. The normal 12V charger, or alternator will charge the batteries when the Jet Thruster system is not used. The dedicated 12-24V battery setup does not affect the 12V system at all.

A: 2 or 3 inch is enough. A Jet Thruster nozzle can be AT the water line, and still function 100%. It's a Jet operation. The nozzle works above and below the waterline. Keep it below the waterline to avoid spray

A: Anywhere you have space available, as long as the pump head is placed below the water line. A Jet Thruster makes use of a not-self-priming centrifugal pump. Because it's placed below the waterline, it will automatically prime due to the positive water pressure to the pump inlet.

A: Anywhere you can, as long as it's well below the waterline. It does not necessarily need to be at the lowest parts, but it can be placed the side of the hull. Keep in mind that the flexible hose between the thru-hull inlet and the pump inlet side can not extend beyond 3ft.

A: There is no particular limit. Because the system operates horizontal with a large flow and a low pressure, the length is not important. We do have to mention that rubber hose absorbs some kinetic energy off the present flow and existing pressure. A short setup of the hoses is always preferred.

A: Absolutely! Thrust is Thrust. If you compare 70Kgf of thrust between a Jet Thruster and a other product, the most important question will be where this force will be applied to the boat. Because the nozzle of the Jet Thruster system can be installed more forward compared to tunnel thrusters, more leverage towards the pivoting point will occur thus more efficiency





Q: Can anything get into the system?

Q: What if a part needs to be serviced or replaced. Does the boat has to come out of the water?

Q: How does the electrical system work?

Q: What about barnacles?

Q: Barnacles are present at SS316 surfaces such as the nozzle and water inlet flanges, do I need to remove them?

Q: Does the system need maintenance?

Q: I leave my boat for longer period of time un-used in sea water (several months) is there any particular maintenance?



A: Very difficult: The water intake is protected by a filter. Plastics and normal rope, used for docking a boat cannot enter the system. Small particles which can pass the filter will be processed by the pump. There is a large flow inside the system, which shoots out sand and other small items easy.

A: After closing the thru-hull valves at the pump-intake and nozzle section, the boat can stay in the water. Water present in the system, can be drained or blown out. Follow the winter-rising instructions in the installation manual to remove water from the system

A: A Jet Thruster makes use of 12v technology to control and engage the system. Direction of thrust is selected by the joystick, the directional valve will choose direction and directly after that the pump will start and run as long as you hold the joystick.

A: Jet Thruster systems are sold world wide. We have no records of system that fail due to barnacles. There are no indications barnacles manifest inside the system, only to the flanges of the thru hull parts. Regular maintenance and inspection is advised.

A: Yes, remove them, and keep the SS316 surfaces clean.

A: No particular maintenance is required

A: Close all valves and rinse out sea water thru the 1/8 pump outlet plug with use of fresh water (e.g. use a water hose with fresh water)





Read prior to operating the Jet thruster system

Your boat is equipped with a Holland Marine Parts electric Jet Thruster. For the safe and correct operation of this system Holland Marine Parts recommends every user to carefully study this operating guide. Familiarise yourself with the system by trying it out in various weather conditions. The windage and draught as well as the weight of your boat are factors contributing to how well the system operates.

#### Warnings:

- The Jet Thruster is not a replacement of the main controls but assists with the execution of difficult manoeuvres.
- Familiarise yourself with the way your boat responds to your operation of the system.
- The electric motor produces heat. The thermal protection limits continuous operation.
- The water inlet is located on the bottom of your boat. Inquire about the exact location of the water inlet grating.
- Prevent the system from sucking in large amounts of sand and dirt. Do not activate it when you have less than 30cm (12") of ground clearance.
- The nozzles of the Jet Thruster are located beneath the water line. Do not activate the system and do not operate the Jet Thruster when there are people, animals or vulnerable items in the vicinity of your boat and the inlet and nozzles.
- Close all the valves when you are not aboard. Inquire about the local regulations in ports with regard to closing the valves.



**Engage the Jet Thruster in pulses of maximum 10 seconds.**

Do not continuous run the Jet Thruster system: it is designed to operate in pulses.

#### Operation:

Make sure all valves are open before the system is activated. You operate the Jet Thruster by activating the system on the front plate of the control panel by pressing the button (A). This switch is illuminated in blue when the system is active. Operate the Jet Thruster by moving the joystick(s) (B) left or right, moving the bow or stern to port or starboard, respectively. When equipped with push buttons, the same procedure applies.



#### Duration of activation:

Move your boat by means of pulses that last a maximum of 10 seconds. The efficiency of the system is determined in part by the battery capacity present. The overheating protection will activate when the system is active for an extended period of time. After the engine has cooled sufficiently this protection is removed. The cooling time is determined in part by the ambient temperature.

#### Jet Thruster Combi:

The control panel is equipped with two joysticks or push buttons. You can move sideways by operating both push buttons for bow and stern at the same time. You can manoeuvre the boat around the centre of rotation by manoeuvring the bow to port and the stern to starboard, or the other way around.

---

## Safety and operating recommendations.



Follow all instructions in this manual. All installers and users of the system must be aware of the mandatory safety regulations as explained in this manual:

- In rare conditions it might be possible that the pump unit of the Jet Thruster does not prime. If you notice a high rpm from the pump unit and no thrust force, do not attempt to prime the pump unit by continuous activating the system. In this situation the Electrical air valve from Holland Marine Parts should be installed to release the air from the pump head. This will prime the pump. **Do not run the pump unit without the presence of water!**
- Engage the Jet Thruster in pulses of maximum 10 seconds.
- Leave maintenance of the system to qualified technicians.
- Do not touch any moving parts of an active system.
- Parts such as the DC pump motor may become hot: do not touch them and do not cover them under any circumstances.
- Avoid having flammable products near the DC pump motor.
- Do not conduct any inspection or maintenance of the system when it is active or activated.
- Do not close any valves of an active system.
- The system is located beneath the water line. Do not remove any parts of the system before all valves have been closed.
- Close all valves when you are not aboard.
- Leave system maintenance to specialists.
- Disconnect the battery cables when conducting maintenance and in the event of long-term absence (e.g. when the boat is not being used in winter).
- Protect the high-pressure hoses from heat / penetration / sunlight / chemicals / chafing. Check on regular basis.
- Avoid physical contact with the water inlet when the system is active.
- Avoid physical contact (swimmers!) with the nozzles and the water expelled by an active system.
- Keep system components dry. Protect system components from contact with (sea) water, humidity.
- Conduct inspections as stipulated in this manual towards the overall integrity of the components on regular basis.
- Check and replace protective anodes on annual basis.
- Annually check if all battery cable connections are tightened securely.
- Open / close all ball-valves each month to test if they open / close well.



## Winterising:



Youtube Channel:  
Jet Thruster - See video



Preferably have the system winterised by a specialist.

**Please note:** Frost/ice can do a lot of damage if you fail to drain the system.  
Use a compressor to remove the water present in the system  
by means of air pressure.

**Please note:** Excessive pressure may damage the system. Check the operating  
pressure you use to pressurise the system with.  
This operating pressure must not exceed 2 bar (30 psi).

Step 1: Disconnect the + cable from the battery.

Step 2: Close all valves.

Step 3: Remove the blind plug or air valve in the outlet (A) of the pump outlet.

Step 4: Screw a compressed-air nipple in the outlet.

Step 5: Pressurise the system. **MAX 2 BAR (30 psi)!**


Step 6: Open the ball valves one by one and close them the instant you hear  
a bubbling sound. Repeat this procedure for every ball valve.

Step 7: Remove the compressed-air nipple.


Step 8: Replace the blind plug or airvalve.

In addition you can drain the pumphouse, therefore remove draining plug  
for draining the pumphouse.


2" / 51 mm



3" / 76 mm



3" / 76 mm



3" / 76 mm



## Troubleshooting:

If the system is not functioning:

Problem	Cause	Solution
<ul style="list-style-type: none"> <li>- Green Led is off</li> <li>- Green Led is off</li> <li>- Green Led is off</li> </ul>	<ul style="list-style-type: none"> <li>- No Power or defective Fuse.</li> <li>- No Power or defective Fuse.</li> <li>- No Power or defective Fuse.</li> </ul>	<ul style="list-style-type: none"> <li>- Check Controller Battery voltage</li> <li>- Check if all connectors are tight</li> <li>- Check - Change the Fuse 20A</li> </ul>
<ul style="list-style-type: none"> <li>- Red Led Flashing fast</li> <li>- Red Led Flashing fast</li> <li>- Red Led Flashing fast</li> <li>- Red Led Flashing fast</li> </ul>	<ul style="list-style-type: none"> <li>- Engine is overheated</li> <li>- There is no common ground cable</li> <li>- Thermal sensor is damaged</li> <li>- Connector is not tight</li> </ul>	<ul style="list-style-type: none"> <li>- Let the Jet Thruster cool down 20+ min</li> <li>- See page 12 for wire schedule</li> <li>- email us for solution</li> <li>- Check if all connectors are tight</li> </ul>
<ul style="list-style-type: none"> <li>- Red Led Flashing slow</li> <li>- Red Led Flashing slow</li> </ul>	<ul style="list-style-type: none"> <li>- Valve not open or closed in time</li> <li>- Valve is stuck</li> </ul>	<ul style="list-style-type: none"> <li>- Re-plug the power cable of Controller</li> <li>- Remove the valve and clean inside</li> </ul>
<ul style="list-style-type: none"> <li>- System is not working</li> <li>- System is not working</li> <li>- System is not working</li> </ul>	<ul style="list-style-type: none"> <li>- Battery dead</li> <li>- Main fuse broken</li> <li>- wrong dipswitch settings</li> </ul>	<ul style="list-style-type: none"> <li>- Measure battery separately</li> <li>- Check and replace the main fuse</li> <li>- Check page 10 for dipswitch setting</li> </ul>
<ul style="list-style-type: none"> <li>- Engine running inverted</li> <li>- Bow and stern wont work</li> </ul>	<ul style="list-style-type: none"> <li>- Wrong dipswitch settings</li> <li>- Wrong dipswitch settings</li> </ul>	<ul style="list-style-type: none"> <li>- Check page 10 for dipswitch setting</li> <li>- Check page 10 for dipswitch setting</li> </ul>
<ul style="list-style-type: none"> <li>- Engine running, no activity</li> <li>- Engine running, no activity</li> <li>- Engine running, no activity</li> </ul>	<ul style="list-style-type: none"> <li>- Engine does not draw water</li> <li>- Polluted system (shallow water)</li> <li>- Damaged impeller</li> </ul>	<ul style="list-style-type: none"> <li>- Place pump unit inlet below water line</li> <li>- Run engine in deep water until clean</li> <li>- Contact your dealer</li> </ul>
<ul style="list-style-type: none"> <li>- System is not efficient enough</li> </ul>	<ul style="list-style-type: none"> <li>- Low battery voltage</li> </ul>	<ul style="list-style-type: none"> <li>- Charge batteries / measure batteries</li> </ul>
<ul style="list-style-type: none"> <li>- Not enough power (JT-50-70-90)</li> <li>- Not enough power (JT-50-70-90)</li> </ul>	<ul style="list-style-type: none"> <li>- Series-parallel does not activate,</li> <li>- system runs at 12V</li> </ul>	<ul style="list-style-type: none"> <li>- Check connections of series switch</li> <li>- Measure if there is 24v on series switch</li> </ul>



## Safety and installation recommendations:

Read prior to installation!




**Follow all instructions in this manual. All installers and users of the system must be aware of the mandatory safety regulations as explained in this manual:**

- In rare conditions it might be possible that the pump unit of the Jet Thruster does not prime. If you notice a high rpm from the pump unit and no thrust force, do not attempt to prime the pump unit by continuous activating the system. In this situation the Electrical air valve from Holland Marine Parts should be installed to release the air from the pump head. This will prime the pump. **Do not run the pump unit without the presence of water!**
- Use appropriate tools for the installation and maintenance of the Jet Thruster.
- Provide the Jet Thruster separate battery(s). **Place the battery(s) as close to the pump unit of the Jet Thruster as possible.**
- Always use a Holland Marine Parts control panel.
- Do not touch any moving parts of an active system.
- Parts such as the DC pump motor may become hot: do not touch them and do not cover them under any circumstances.
- Avoid having flammable products near the DC pump motor.
- Do not conduct any inspection or maintenance of the system when it is active or activated.
- Do not close any valves of an active system.
- In case of grounding the boat, don't run the thruster. This can reflect in a blocked 3-way valve.
- The system is located beneath the water line. Do not remove any parts of the system before all valves have been closed.
- Close all valves when you are not aboard.
- Disconnect the battery cables when conducting maintenance and in the event of long-term absence (e.g. when the vessel is not being used in winter).
- The hoses are under pressure in an active system: high-pressure hoses are to be attached to the vessel to prevent movement along e.g. sharp edges.
- Protect the high-pressure hoses from heat / penetration / sunlight / chemicals / chafing.
- Avoid physical contact with the water inlet when the system is active.
- Danger! Protect pump unit and 3-way valve from petrol fumes. Provide sufficient ventilation. Ignition proof covers are available.
- Keep system components dry. Protect system components from contact with (sea) water, humidity.
- Connect Sacrificial anodes as explained in this manual to all sections of the Jet Thruster system to reduce the effects of pitting and crevice corrosion to stainless steel parts



## Exploded View Jet Thruster JT-30 Single Compact




Pump unit JT-30	JT-30-50
2-Way pump outlet	P-507-52
3-Way valve	V-500-00

Water inlet	I-302-00
Ring 3"	I-303-00
Nut 3"	I-304-00
Seal Rubber	I-306-00
Elbow 90° 3" BSP	I-307-00
Reducer 3" BSP / 2,5" BSP	I-308-00
Ball valve 2,5" BSP	I-309-00
Hose connector 2,5" / 76 mm	I-310-00


Hose clamp 77-94 mm	I-331-00
Hose 3"/76 mm / L=1m/3.3 ft	I-312-00
Pressure hose 2" / 51 mm	I-113-52
Hose clamp 48-60 mm	I-114-00
Elbow 45° 2" BSP M/F	I-316-00
Hose connector 2" / 51 mm	I-115-00
Ball valve 2" BSP	I-321-00
Nozzles	I-336-00




## Exploded View Jet Thruster 50 Combi Compact



## Exploded View Jet Thruster 50 Single Compact Vertical




## Exploded View Jet Thruster JT-70/90 Single




Pump unit JT-90	JT-50 JT-90 <b>24V</b>
2-Way pump outlet	P-259-00
3-Way valve	V-200-50

Water inlet 4"	I-267-00	Hose 110 mm / L=1m/3.3ft	I-268-01
Nut 4"	I-261-00	Pressure hose 3" / 76 mm	I-213-00
Ball valve 4" BSP	I-269-GF	Elbow 45° 2" BSP M/F	I-316-00
Hose connector 110 mm	I-275-01	Hose connector 3"/76 mm / 2" BSP	I-215-00
Hose clamp 77-94 mm	I-331-00	Ball valve 2" BSP	I-321-00
Hose clamp 115-145 mm	I-270-02	Nozzles	I-336-00

## Exploded View Jet Thruster JT-70/90 Combi




## Exploded View Jet Thruster JT-70/90 Vertical Single




## Technical Specifications JT-30


### Pump head in position I



P-115-52: Straight pump outlet



P-513-52: 90° pump outlet




P-507-52: 2-way pump outlet







3 options for hose conne  
on pump outlet:

#### Water inlet assembly:

Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft




Inlet




## Technical Specifications JT-30


### Pump head in position II



P-115-52: Straight pump outlet




P-513-52: 90° pump outlet









P-507-52: 2-way pump outlet

3 options for  
hose connector  
on pump outlet:




#### Water inlet assembly:

Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft




# Technical Specifications


## JT-30 Compact Vertical





P-115-52: Straight pump outlet



P-513-52: 90° pump outlet




P-507-52: 2-way pump outlet



## JTV-30-50 12V


### Jet Thruster Vertical 30Kgf




## Technical Specifications

### JT-50 Compact


#### Pump head in position I





P-115-58: Straight pump outlet








P-513-58: 90° pump outlet



P-507-58: 2-way pump outlet



**Water inlet assembly:**  
Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft







## Technical Specifications

### JT-50 Compact


### Pump head in position II



P-115-58: Straight pump outlet




P-513-58: 90° pump outlet









P-507-58: 2-way pump outlet

2 options for  
hose connector  
on pump outlet:




#### Water inlet assembly:

Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft




# Technical Specifications


## JT-50 Compact Vertical



P-115-58: Straight pump outlet






P-513-58: 90° pump outlet




P-507-58: 2-way pump outlet

3 options for hose connector  
on pump outlet:




## JT-30 / JT-50 Vertical installation instructions



The Jet Thruster Vertical Compact pump unit can be placed directly to the hull with use of the dedicated Spacer and Water inlet.

With the supplied tool, it is easy to screw in the water inlet from the outside of the boat directly into the pump head, locking all parts of pump and inlet connect firmly and secure in place.


Because the pump head is close to the hull, the Jet Thruster Vertical is an ideal Jet Thruster for boats with shallow draft such as Waterskiing and wakeboarding boats.



Position of pump: As long as you keep the blue pump head below the waterline, the pump can be placed anywhere inside the boat.

Note: If you do not place the pump head below the water line, the Jet Thruster system will not work: Check the boat to find the waterline!


It's possible to position the pump under an angle. In many cases this is the only option. If required you can use the provided bracket to support the weight of the pump.



Search for a flat surface. The Surface diameter to accommodate the guide ring must be at least 150mm

If you place the guide ring on the hull, and you notice the surface is not flat: Smoothen the hull, or cut out plastic from the guide ring.

Guide ring will act as foundation for the pump head. It important to ensure a perfect fit for the guide ring to the hull.



The 3" BSP threads of the Water Inlet I-302-00 have a length of 90mm. It's very important to measure the thickness of the hull: Together with the Spacer, and threads present in the pump head this thickness of the hull will determine how much length must be cut the inlet to the right length.



Note: It's very important to make a clean cut. It's obvious that the Water Inlet Thread will be damaged due to the cutting process. Before you screw the modified inlet into the pump, make sure there are no burrs that can damage the thread of the pump head!


Before you cut into the Water Inlet Treads: Place the Provided 3" nut. After you cut, use the nut to test if the threads are ok. If the nut does not move, do not use force. Use a file to remove burrs and irregularities.

#### Example

Threads inside pump head	25mm
Spacer	20mm
Hull thickness visible after you drilled the 90mm inlet opening: (Example, this will vary for each boat)	20mm
Total length required to connect the parts	65mm
Water Inlet available threads length	90mm
CUT = 90-65	CUT 25mm



Note: In case you know the exact hull thickness, Holland Marine Parts can provide a dedicated cut-to-length Water Inlet.



- Thoroughly clean all parts, threads and surfaces with Acetone.
- Test fit the modified Water Inlet in the pump head, but be careful not to damage the pump head threads
- Apply sufficient Sikaflex 291i / PU Sealant to all parts as indicated in the picture


Have one person present inside the boat who will hold on the Pump assembly

Have one person present outside the boat to continue with the following steps:


- Apply sufficient Sikaflex 291i / PU Sealant to the flange of Water inlet.  
By turning the wrench/tool and Water inlet during the process, PU Sealant will be pressed out, this is normal
- Use provided tool and wrench to tighten the water inlet into the pump
- Maximum tighten the inlet: This will lock the assembly in place  
Use Wet Wipes to easily remove spilled sealant from parts, tools and hands.
- Wet Wipes I-391-00 ensure a spotless installation, and are highly recommended.

## Technical Specifications JT-70


### Pump head in position I



P-242-00: Straight pump outlet




P-222-00: 90° pump outlet








P-259-00: 90° pump outlet

2 options for hose connector  
on pump outlet:




#### Water inlet assembly:

Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft




## Technical Specifications JT-70

### Pump head in position II




P-242-00: Straight pump outlet



P-222-00: 90° pump outlet








P-259-00: 90° pump outlet





#### Water inlet assembly:

Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft






## JTV-70-50 24V 70Kgf




## Technical Specifications JT-90

### Pump head in position I



P-242-00: Straight pump outlet




P-222-00: 90° pump outlet








P-259-00: 90° pump outlet

2 options for hose connector  
on pump outlet:




#### Water inlet assembly:

Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft




## Technical Specifications JT-90


### Pump head in position II



P-242-00: Straight pump outlet




P-222-00: 90° pump outlet








P-259-00: 90° pump outlet

2 options for hose connector  
on pump outlet:







#### Water inlet assembly:


Connect with flexible hose to inlet on pump unit.  
Max. hose length 1 m / 3.3 ft




## JTV-90-50 24V 90Kgf



## JT70 / JT90 Vertical pump position



1	Dc motor, 11 / 15.5Kw	P-319-00
2	Seal	I-604-00
3	Intermediate Flange Water	I-618-01
4	Hexagon cylinder bolt M10x35	F-210-00
5	Water inlet	I-616-00
6	Hexagon socket countersunk head M10x50	F-222-00
7	Seal Pump outlet	P-260-00
8	Pump outlet straight 2'5" threaded	P-256-00
9	Hexagon Cylinder bolt M8x35	F-208-00
10	Ball valve 25"	I-309-00
11	Pump Bracket JT90	P-216-00




### Position of pump unit:

- Select a perfect flat position for the pump unit. If not flat, the hull must be made flat
- Select a horizontal position. Pump motor must be in vertical position.
- Pump unit must be placed below the waterline
- Pump unit must be fixed to the interior. It's important to support the weight of the pump motor.  
Construction can be attached to the pump bracket for that purpose






### Installation process:

- Mark drill pattern to the outside of the hull, flange I-616 serves as template
- Drill 8x Ø11mm holes
- Drill 1x Ø112mm inlet hole
- Dry fit the complete assembly
- Thoroughly clean all parts that will be in contact with Sikaflex 291i marine sealant with acetone.
- Use sufficient Sikaflex 291i to fix the Stainless steel pump flange to the inside of the vessel.  
To avoid leaks, the hull must be perfectly flat. Sikaflex will provide a excellent seal
- Use sufficient Sikaflex 291i to provide a high quality seal at the Inlet Flange I-616-00
- Tighten 8 exterior bolts to fix the complete assembly
- Remove excessive Sikaflex with I-391-00 Industrial wipes








**Warning:** F-222-00 bolt provides sufficient thread for **hull thickness of 5-22mm**.  
In case you have a different hull thickness, a different bolt length must be used:  
Consult Holland Marine parts to avoid permanent damage to the pump and your boat.

## Technical Specifications 3-way valve JT-30 Composite (52mm)










## Technical Specifications 3-way valve JT-50 (58mm)



# Technical Specifications 3-way valve JT-70 / JT-90



## Installing the Jet Thruster components:



All orifices are located below the water line. Extra attention needs to be given to securing and installing the included hose clamps around the pressure hoses. The included hose clamps are robust and of high quality.



Holland Marine Parts recommends using hose clamps which are provided with the installation kit. The installation of different hose clamps than the ones included with the system is at your own risk.

### Mechanical Installation:

Keep the following points in mind during the mechanical installation:

**A: position of pump unit and water inlet combination**

**B: position of 3-way valve**

**C: position of nozzles**

**Note:** The Jet Thruster is most efficient when the connections between system components made with the included pressure hoses are as short as possible. Place the pump unit and the 3-way valve as close to the nozzles as possible to achieve this.

### Hose clamps:



#### Torque:

77-94mm (I-331-00) 45Nm  
60-78mm (I-116-00) 40Nm  
48-60mm (I-114-00) 40Nm

Installation kit provides 1 hose clamp per bushing.

### Pay attention when installing the provided Müllenbach two-shell hose clamps:

- Make sure all parts of the clamp slide into place when tightening the nuts.
- Make sure clamps are well placed and thoroughly fastened.
- After first operation of the system, check that clamps are tight.
- Inspect the clamps for their integrity annually.



For use in salt water environment;  
To avoid corrosion, apply e.g. Protective spray to the clamp (Vaseline).




## A: Position of pump unit and water inlet combination

It is important to select a position for the pump unit at which it is located under the waterline.

The centrifugal pump does not self prime! If the pump is placed close to the waterline, or in case of fast moving vessels is can be necessary to install the optional Electrical air valve that will help to rapidly prime the pump. In addition to select the optimum position of the pump unit Holland Marine Parts advises to **place suitable battery's directly next to the pump unit in order to keep the battery cabling as short as possible!** The jet thruster uses a lot of electrical energy in a short period of time. **Short and correct battery cabling is mandatory in this situation!**

- pump unit must be installed below water line.
- Place the water inlet in the hull of the vessel.
- Exterior of hull: Flange of water inlet.
- Interior of hull: PP sliding ring, nut.




**Please note:** Keep a maximum distance of 1 metre (3,3 ft) between the hose connector of the pump and hose connector on the ball valve assembly. 1 metre (3,3 ft) hose is provided for this purpose (I-312-00)

**Please note:** Exterior of hull: Apply a PU Marine Sealant (Polyurethane) on the flange of Water Inlet.




Connections of stainless steel parts must be performed with a pu (Polyurethane) sealant.



water intake side

← Standard configuration: 3" 90° degree elbow BSP SS 316, provided in installation kit.



water intake side

← Option in case of steep hull or problems with alignment:

### Available as option:

JT 30 / JT 50

1x Female / Female 3" BSP 45° elbow: I-354-00

1x Male / Female 3" BSP 45° elbow: I-364-00

JT 70 / JT 90

2x male / female 4" BSP 45° elbow: I-272-00





Pump head position and pump outlets can be changed.  
Contact your dealer or Holland Marine Parts for additional information.

### **Longitudinal placement:**

For longitudinal placement attach the 90° hose connector + rubber seal to the pump head.

### **Pump head position I**




JT30/JT50



2" / 58 mm



2" / 52 mm



JT70/JT90




3" / 76 mm

### **Lateral placement:**

For lateral placement attach a straight hose connector + rubber seal to the pump head.

### **Pump head position II**




JT30/JT50



2" / 58 mm



2" / 52 mm



JT70/JT90



3" / 76 mm

## B: Position of directional 3-way valve



**CAUTION:** Prevent physical injury! When electrically turning the plunger present in the valve body, considerable force occurs. Prevent any body parts from getting trapped during installation.

**Please note:** *By opening the lid of the valve, the watertight seal and bearing is broken. Opening the valve will void your warranty.*

- Place of the 3-way valve as close to the nozzles as possible.
- Mount the 3-way valve to the boat. Use the recesses at the bottom of the valve body for this. (m8)  
Position not necessary horizontal. It is possible to place the valve upside down or to the side (do not let it rest on the cover).
- Always use the protective cover to protect the electrical parts.
- Can be placed above or below waterline in any position

### Jet Thruster Combi:

Dirt or sand that drift in the ocean can build up in the system, this will be flushed out during use. The function of the 3-way valve allows for an amount of water flowing through, even when the valve is not in use. However, in case of grounding or suction of a lot of amount of sand and dirt. The 3-way valve can loose function. Open the bolts and cleaned the system out.



V-100-50 / V-200-50



## C: Position of the nozzles

- Based on the type of hull you have chosen a certain nozzle type. Select this nozzle type and the corresponding installation instructions from the below scheme.

**Please note:** Nozzles JT 30 and JT 50 are equipped with an internal Venturi. Do not damage or remove this constriction!

Steel	I-318-00	65 mm (2.59")	cut off remaining length
SS316	I-320-00	60 mm (2.36")	cut off remaining length
Aluminium	I-322-00	60 mm (2.36")	cut off remaining length
0°	I-324-00	60 mm (2.36")	no finishing needed
25°	I-330-00	60 mm (2.36")	no finishing needed
35°	I-333-00	60 mm (2.36")	no finishing needed
35° Sailing Yacht Curved	I-333-00 SY	60 mm (2.36")	no finishing needed
45°	I-336-00	60 mm (2.36")	no finishing needed
45° Sailing Yacht Curved	I-336-00 SY	60 mm (2.36")	no finishing needed
55°	I-339-00	60 mm (2.36")	no finishing needed
65°	I-341-00	60 mm (2.36")	no finishing needed
Flange threaded 90° transom	I-342-00	60 mm (2.36")	no finishing needed



Do not paint flanges with anti fouling;  
See next chapter for nozzle information.



nozzle 0°



nozzle 25°



nozzle 35° - nozzle 35° SY



nozzle 45° - nozzle 45° SY



nozzle 55°



nozzle 65°



transom 90°



nozzle aluminium



nozzle SS316





nozzle steel





- The Jet Thruster will be most effective when the nozzles are placed **AS FAR FORWARD OR AFT AS POSSIBLE**.  
(shifted position possible as seen in diagram, to increase leverage arm).
  - Top side of nozzle 7-10cm (2.5"/3") below waterline.
  - Keep in mind that when the nozzles rise above the waterline, it is possible by the powerful Jet of water expelled by the Jet Thruster inconvenience or damage may occur.
- Use the included 45 degree elbows in order to place the nozzles as far as forward or aft as possible.

In case of application as a stern Jet or in case of Jet Thruster Combi: place the system as far as possible to the stern.  
If 90° Transom nozzles are installed in the stern, the system will be most efficient.



## Nozzle positions and installation options

**Note:** The standard installation kit provides 1 x 2" 45° elbow.  
Additional parts must be ordered separately.




**Note:** If you do not need the 45° elbow in your installation: do not use it.

1 x 2" BSP 45° elbow to each nozzle.





I-361-00  
2" BSP, m/f, SS316




### 1. Crossed nozzle position



### 2. Horizontal shifted nozzle position



### 3. Vertical shifted and crossed nozzle position



## Installing the nozzles and water intake.




Learn more at:

[www.youtube.com/user/hollandmarineparts](https://www.youtube.com/user/hollandmarineparts)

In case of steel or aluminum vessel plating weldable nozzles are available.

For polyester and wooden vessel plating flange threaded nozzles are available.



**1:** Place vessel horizontal. Select optimum position for nozzle: As far to the front of bow or stern as possible, top side of nozzle 10cm / 4" below water line. Nozzle horizontal and in 90° angle to the heart line of the vessel.

**Note:** *Not placing the nozzles as far to the front or aft as possible reduces the overall effectiveness of the system!*

Laser equipment can assist selecting optimum position and determine if vessel is placed perfectly horizontal.



**2:** Make sure the position of both nozzles and the components like the ball valves, elbows, hose connector, hoses and hose clamp are not in conflict with available space before a hole is made.

Drill a pilot hole. Keep drill horizontal!

Nozzles can be positioned shifted horizontal and vertical in case of a narrow bow. Hoses can be crossed in order to place the nozzles further to the front of the bow. See image at point 8 for visible explanation.




**3-4:** Use a 60mm / 2 3/8" hole saw to drill the holes for the nozzle.

Keep drill horizontal and in 90° position to the vessel's heart line.



**5:** Smoothen edges



**6:** Fit in the nozzle and check if nozzle is placed horizontal and in 90° angle to the heart line of the vessel e.g. by inserting the nozzle from the inside out to determine if hole is drilled correct.




#### 7: Outside of vessel:

**Weldable nozzle:** Weld in the nozzle and cut of remaining length. Smoothen surface.

Note: Do not cut into, or cut away the internal restriction within the nozzle!



**Flange treaded nozzle:** In case of an rough or not entire flat surface: Apply sealant for maritime purposes: Sikaflex-291i / 3M 5200 adhesive / sealant on the side of the flange of the nozzle that contacts the vessel plating.



In case of a smooth and flat surface: Apply the provided rubber seal.

Do not use additional sealant in combination with the rubber seal.


#### Inside vessel:

Place the PVC guide ring, white nylon ring and the 2" nut, apply sealant. Tightly fasten the nut. Make sure the nozzle remains horizontal and in 90° heart line of the vessel.



**8:** Connect the ball valve, 45° elbow and the hose connector. All connections are BSP treaded. Apply PU Sealant for maritime purposes: e.g. Sikaflex-291i / 3M 5200 adhesive / sealant at every tread to connect and seal the parts.

**Do NOT use teflon tape!**



**9:** Thoroughly clean and degrease every tread that has to be connected. Make sure to use sufficient sealant on the tread. At least 6 threads and smoothen with e.g. finger over entire thread. Apply sealant on both parts that have to be installed. Remove spilled sealant immediately. Use wet whipes (I-391-00) to remove Sikaflex-291i stains.



wet whipes (I-391-00)



**10: Installing the water intake:** The position of the pump unit that has to be installed under the water line determines the location of the water intake. Make sure the position of the water intake and the components like the ball valve, elbow, hose connector, hoses and hose clamp are not in conflict with available space before a hole is made.



**11:** Repeat installation process like suggested at point 7.



**12:** Thoroughly secure the flange treaded water intake by fasten the provided 3" nut.

## Conservation of stainless steel components:

### Preparation prior to anti fouling

Stainless steel has a natural ability to form a protective film which protects it from corrosion. In basis this is the reason why the stainless steel is corrosion resistant, but there are things to take into account: In case of a lack of oxygen, this film cannot be formed and corrosion (pitting/crevice corrosion possible will occur) Especially in warm salt water areas it's important to understand how to keep the parts free from corrosion:



There are 2 way to avoid corrosion to stainless steel parts:

#### Option 1:

- Do not paint stainless steel surfaces solely with antifouling or other paint systems.  
If you paint the hull with anti fouling, do not paint the stainless steel parts
- **Keep stainless steel surfaces free from barnacles, or all other fouling.**  
Remove fouling as soon as possible. Keep surfaces clean. Do not scratch the surfaces with metal tools.
- **Run the Jet Thruster system:**  
By using the Jet Thruster System you clean it and fresh oxygen-rich water ensure formation of the protective film

#### Option 2:

If painting of stainless steel surfaces is required: When you prefer to paint stainless steel parts with anti fouling

#### **Important!**

First the SS316 parts must be coated with a water and vapor proof epoxy primer.

All stainless steel parts must be thoroughly cleaned and sanded (sand blasted)

Use quality Epoxy primer suitable for stainless steel surfaces: At least 5 layers, and finally a antifouling must be processed to ensure a vapor proof coating of the stainless steel surface. Nozzles and water inlet must be coated on the in- and outside.

**Note:** There are many different Epoxy primer and paint systems available.

Ask the professional supplier of these products for the right products, surface preparation, film thickness and methods of application to ensure a water and vapor proof coating of the submerged stainless steel parts. If this coating is not vapor proof, most likely corrosion will occur.



## Cathodic Protection:

Connect the optional Zinc Anode System to the Jet Thruster Pump Unit to protect Stainless Steel parts from corrosion.


Parts:

- JT30/JT50: CP-001-00
- JT70/JT90: CP-002-00
- JT70/JT90: CP-050-00




- Anode must be inspected / replaced when worn out.
- Verify no live battery cables or live + cables make contact to Stainless Steel parts at any time!

### Frontside JT30/JT50



### Frontside JT70/JT90



A: CP-003-00 Anode Holder

B: CP-004-00 Zinc Anode


C: P-260-00 Seal

D: E-114-00 Cable set JT30/JT50

E-115-00 Cable set JT70/JT90




JT70-JT90 pump outlet



JT70-JT90 pump inlet

### Backside JT70/JT90

To water inlet



---

## Protect your Jet Thruster system from corrosion:

Sea- or brackish water, even polluted fresh water conducts electricity very well. Stainless steel can suffer from corrosion (pitting/crevice corrosion) when there is a lack of oxygen to restore the protective film that gives the stainless steel its natural protection:

Takes these following recommendations into account to assure corrosion is discovered, detected, removed, and prevented.



- Do not paint the stainless steel surfaces of the water intake and nozzle flanges present on the outside of the hull
- Remove barnacles, marine- and all other possible fouling from stainless steel surfaces as soon as possible, when present.
- Do not use steel tools (other than stainless steel) or steel wool when cleaning any stainless steel surface. Use Scotchbrite.
- Connect all stainless steel parts to a sacrificial anode, follow recommendations in this manual.
- Do not paint Anodes.
- When using copper- or tin-based anti-fouling (if not prohibited by local law) electrical interconnection must be avoided between the Stainless steel Jet Thruster components and the anodic blocks. Make sure to keep 40mm unpainted area around these items.
- If you use shore power, you should have an approved galvanic isolator or separator installed to protect against Stray Current Corrosion (electrolysis) from your dock.
- Your particular boating environment may require that you install additional anodes or other protective devices
- Corrosion is often induced by certain types of bacteria present in the water (world wide) and leaking electricity from false- or damaged electrical equipment. (Stray current)
- Galvanic or electrochemical corrosion to your stainless steel Jet Thruster components is minimized with a sacrificial anode if correct connected.
- Corrosion can be caused by many factors, such as wrong type or improper application of anti-fouling paint, marine growth, stray electrical current (electrolysis) etc.

### Why can unpainted flanges of the water inlet and nozzles become discolored or rusty?

- Stainless steel can discolor and form areas of light rust. Brushed finished stainless steel surfaces are more susceptible than brightly finished stainless steel. Rust stains can occur from polluted water, galvanic corrosion from the boat or marina, or from oxygen depletion. The stainless steel surfaces can be easily cleaned with rubbing compound or Scotchbrite. **DO NOT USE STEEL WOOL.** After cleaning use chrome polish to protect the finish. Stainless steel surfaces can also turn white from calcium or lime in the water. In this case clean the stainless steel surface with household mineral bath and tile cleaner.
- Important: Never use Steel Wool or any other metal parts or tools on the stainless steel Jet Thruster parts and surfaces. Do not grind or weld near stainless steel parts.
- Always avoid contact between stainless steel parts and other metal parts to avoid rust, or other types of corrosion to the stainless steel.
- Be vigilant for signs of corrosion and act if noticed to avoid (further) damage or dangerous situations.



## Cathodic Protection of nozzles - CP-010-00

Incl.: - Disc anode Ø90mm  
- Bolt M8 / nut / washers  
- Cable assembly



- Anode must be placed close to bow or stern nozzles.
- Do not paint the Anode.



**1**  
Remove the antifouling







**2**  
Drill and cut thread M8



**3**  
Use Sikaflex to seal the bolt M8



**4**  
Place washer




## Optional zinc anode JT30/JT50



- Anode must be inspected / replaced annually
- Verify no live battery cables or live + cables make contact to Stainless Steel parts at any time!

Cable set to metal motor flange  
Cables are included with zinc anode




Optional pump outlets




		JT-30	JT-50	
	€ 62,-	P-156-00	P-156-00	Pump outlet threaded
	€ 47,-	P-142-52	P-142-58	Pump outlet straight
	€ 110	P-122-52	P-122-58	Pump outlet 90 degrees
	€ 145,-	P-155-52	P-155-58	2-Way 90 degrees hose connector
	€ 175,-	CP-001-00	CP-001-00	Zinc anode holder JT30-JT50
	€ 56,-	CP-004-00	CP-004-00	Replacement Zinc anode JT30/ JT50
	€ 5,-	CP-005-00	CP-005-00	Seal for Outlet Zinc Anode



# Pump outlet zinc anode JT70/JT90


Option 1



Cable set to water inlet and flange  
Cables are included with zinc anode





	€ 175.-	CP-002-00	Zinc anode JT70/JT90 Pump outlet
	€ 56.-	CP-006-00	Replacement Zinc anode JT70/ JT90





# Water inlet zinc anode JT70/JT90

Cable set to water inlet and flange  
Cables are included with zinc anode



Option 2

	€ 195.-	CP-050-00	Zinc anode water inlet JT-70/JT90
	€ 85.-	CP-051-00	Replacement Zinc anode JT70/ JT90



Corrodium BV  
Planetenweg 5  
2132 HN Hoofddorp  
00 31 85 2733501  
Fax 0031 85 2733502  
info@corrodium.nl



Holland Marine Parts  
Heijningen  
Report

## Inspection and Maintenance Jet Thrusters

### Materials Selection and Corrosion

Document Number  
**214065**

Revision No.  
**00**

Revision Date  
**17 July 2014**

Author/signature	Verifier/signature	Revision Number	Date
		03	
		02	
		01	26 juni 2014
Ing. Jan J.M. Heselmans	Esther de Valck	00	20 mei 2014

## Content

1	Scope of Work	2
2	Materials Selection and Possible Corrosion Mechanism	2
2.1	Nozzles	2
2.2	Valves	2
2.3	Galvanic corrosion Nozzles/Valves	2
2.4	Pumpunit	2
3	Maintenance and Inspection	3
3.1	Nozzles	3
3.2	Valves/Nozzles Threading	3
3.3	Pump	3
4	Frequently Asked Questions (faq)	3



## Scope of Work

Holland Marine Parts Jet Thrusters have been made of corrosion resistant alloys. However, under extreme conditions corrosion problems might occur. For this reasons it's important that a regular inspection is done.

This report will describe which type of corrosion might occur on which locations. And how to inspect on corrosion.

## Materials Selection and Possible Corrosion Mechanism

### 1.1 Nozzles

The nozzles have been made of cast alloy 1.4408. This is a 316 type stainless steel (19 Cr, 10 Ni and 2 Mo). In seawater and brackish water, 1.4408 may corrode by pitting corrosion and crevice corrosion on the threading with the valves. The pitting corrosion might be accelerated by MIC (Microbiological Influenced Corrosion). MIC mainly occurs at higher temperatures of the water, during summer time or in (sub)tropical waters.

### 1.2 Valves

The valves have been made of brass alloy Cu58Zn38 and have been coated with a Chromium layer of 2-3  $\mu\text{m}$  thickness. Such valves are suitable for ships in marine conditions (seawater condition). Corrosion might occur if the chromium layer has been damaged or has been worn out.

### 1.3 Galvanic corrosion Nozzles/Valves

Galvanic corrosion between nozzles and valves is unlikely. Both have the same rest potential (same nobleness). Both contain a surface layer of chromium oxides.

### 1.4 Pump unit

The pump house has been made of a plastic with a stainless steel back sheet. The impeller (JT70 and JT90) has been made of a bronze cast alloy. In well conducting waters, such as seawater, galvanic corrosion of the pump impeller caused by the stainless steel back sheet is possible. (JT30 and JT50 have non corrosive composite impeller)

## Maintenance and Inspection

All parts have been made of corrosion resistant materials. However under extreme conditions corrosion is possible. For that reason we advice an inspection interval of 6 month.

### 1.5 Nozzles

Inspect the nozzles once every six month on corrosion and fouling from the outside of the vessel. If corrosion or fouling can be seen, remove it with a brush and inspect the surface (and welds if applicable) again on pitting corrosion.

### 1.6 Valves/Nozzles Threading

Inspect once every six month the threading of the couplings on leakages. If leakages are found, possibly crevice corrosion of the threading occurs. Loose the coupling and inspect it on corrosion of the threading's internal and external.

### 1.7 Pump

During longer stand still periods it is recommended to store the pump internals in air, or in fresh water. If seawater or brackish water is in the pump for a longer time (month), we recommend to inspect the impeller on corrosion problems.

## Frequently Asked Questions (faq)

Q: For the nozzles: Can a coating help to avoid corrosion?

A: Yes, a coating can help on the external part. Internally the nozzles cannot be coated as the water flow is too high. A coating will loosen from the stainless steel surface.

Q: How should stainless steel be coated?

A: Stainless steel can be coated, but the adhesion of the coating always will be less good compared to carbon steel. The coating procedure is similar to carbon steel:

1. Proper surface preparation by grid blasting. High roughness is of great importance.
2. The surface must be completely clean, particularly free of chlorides (salt).
3. Use several layers of (primer) epoxy, according to marine coating specs.

Q: What protection will polishing the stainless steel surface guarantee?

A: Polishing always is good for two reasons:

1. Corrosion resistance will improve.
2. Biofouling and MIC will be reduced.

Q: Can biofouling promote corrosion, such as crevice corrosion or MIC?

A: Yes, biofouling preferably must be removed.

Q: How can pitting corrosion be repaired?

A: If the pits are not deep, the can be grinded out smoothly succeeded by polishing the surface. If the pits are deep, the need to be welded and the surface must be grinded again.



Q: How can crevice corrosion be repaired?

A: If the corrosion is not deep, the can be grinded out smoothly succeeded by polishing the surface. If the pits are deep, they need to be welded and the surface must be grinded again.

Q: How can MIC be stopped?

A: MIC is a biofilm problem. The biofilm is bio fouling, or a slimy layer of micro organism. MIC can be stopped by removing the fouling and biofim. I.e. by cleaning the surface.

Q: Can 'free iron', or 'iron oxide' cause corrosion to stainless steel?

A: Yes, this should be avoided. For example, don't grind steel near stainless steels.

Q: How can a contaminated or activated stainless steel surface be repaired?

A: This can be done with a 'pickling and passivation' paste. Be careful, this are toxic acids (containing Hydrogen Fluoride). Read manual carefully, take safety precautions. Be careful with acids on other materials such as marble. Always rinse all acids out using clean tap water.

Q: Can stainless steel be protected with sacrificial anodes (Zinc or Aluminium)?

A: Yes, cathodic protection will stop the corrosion of stainless steel. If the nozzles are contacted with the steel hull, the anodes on the hull will protect the nozzles (if anodes are present). It will not be possible to attach anodes to the nozzles if they are insulated in a GRP (polyester and other) hull.

Q: Can galvanic corrosion cause corrosion to the stainless steel nozzles?

A: Normally not because stainless steel is high (noble) in the galvanic range. If stainless steel is connected to carbon steel, the ignoble carbon steel will corrode, and the noble stainless steel will be cathodically protected by the steel.

Q: Can stray currents cause corrosion to the nozzles?

A: Only if the stray current runs through the water from one electrode to the other one (the nozzle). An electrical circuit must be drawn in order to explain this. Stray currents causing corrosion are rare.

Certification with added value

DUTCH  
CERTIFICATION  
INSTITUTE

Member of Lloyd's Netherlands®

[www.dciworldwide.eu](http://www.dciworldwide.eu)



### Certificate of Conformity

Dutch Certification Institute, Notified Body for certification of Recreational Craft to the Directives 94/25/EC as amended by 2003/44/EC under number 0613 and established at Joure, the Netherlands, herewith declares that the under mentioned product has been assessed and meets all applicable essential safety requirements.

Manufacturer: Holland Marine Parts  
Donker Duyvisweg 297  
3316 BL Dordrecht ( NL)

Product description: Centrifugal pump based Thruster system  
for Bow and Stern

The enclosed list with essential documents of the Technical Documentation forms a whole with this certificate. This certificate remains valid as long as the product is up to the assessed prototype and follows the instructions: Correct use of the certificate.

Thus made and drawn up at Joure, the Netherlands, in good faith and to the best of knowledge.

Certificate number : CE - RCD- 1463  
Date of Issue : 16<sup>th</sup> April 2015

Mrs. G.T. Hoekstra  
*Head of certification*

## Annex A

### Essential Documents of the Technical Documentation

Date: 16<sup>th</sup> April 2015

Attachment of certificate: CE-RCD-1463

#### Elucidation of the certificate:

The under mentioned essential documents of the Technical Documentation have been assessed for compliance with the essential safety requirements regarding the design and the construction for building of recreational crafts, Annex I of the Recreational Craft Directives 94/25/EC and 2003/44/EC.

#### 1. Verification documents:

Technical file: 1358.15

#### 2. Test reports:

2.1 Test report: SIQ Ljubljana  
Report number: T251-0033/15  
Report date: 15<sup>th</sup> December 2014

2.2 Test report: TÜV Rheinland  
Project number: 15020409.e01  
Report date: 27<sup>th</sup> March 2015

#### 3. Product identification: The identification of the prototype is:

**JT 30** - 12v , 3 kW  
12v , 3.85

**JT 50** - 12v , 6 kW  
24v , 6 kW

**JT 70** - 24v , 11 kW

**JT 90** - 24v , 15.5 kW

including: hose clamps "Müllenbach" type 48-60 and 77-94

#### 4. Applied standards:

EN 60204-1:2006  
EN 60034: 2010

EN 61000-6-3: 2007 incl Amd. A1: 2011  
EN 61000-6-4: 2007 incl. Amd. A1: 2011

Mrs. G.T. Heckstra  
*Head of Certification*

---

## 4. EU Declaration of Conformity (no.17K001) Jet Thruster controller

We,

Manufacturer	Karyvo
Adress	Zeilmakersstraat 3a
	8601 WT Sneek
	The Netherlands

Declare under our sole responsibility that:

Product:	Multifunction Controller for Marine Applications
type:	Jet Thruster Controller

Is in conformity with the relevant Union harmonization legislation:


2014/30/EU	The Electromagnetic Compatibility Directive
2011/65/EU	The Restriction of Hazardous Substances Directive
2012/19/EU	The Waste of Electrical and Electronic Equipment Directive

Conformity is shown by compliance with the applicable requirements of the following documents:

Reference & Date	Title
EN ISO12100:2010	Safety of machinery. General principles for design. Risk assessment and risk reduction
EN55014-1:2006 +A2:2011+A1:2009	Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus - Part 1: Emission
EN55014-2:1997 +A2:2008+A1:2001	Electromagnetic compatibility - Requirements for household appliances, electric tools and similar apparatus - Part 2: Immunity - Product family standard

All components used are conform 2011/65/EU (RoHs Directive)

Sneek 02/02/2017



Karyvo VOF.



## ABYC Certificate



*Dutch Certification Institute, testing and certification body established at Joure, the Netherlands, herewith declares that the under mentioned product has been assessed according to module B and meets the applicable essential safety ABYC requirements, chapter H-27/UL1121.*

*Manufacturer:* Holland Marine Parts  
Donker Duyvisweg 297  
3316 BL Dordrecht  
The Netherlands

*Product description:* Composite Nozzles

*Types:* I-324-GF-00  
I-330-GF-00  
I-333-GF-00 / I-333-GF-SY-00  
I-336-GF-00 / I-336-GF-SY-00  
I-339-GF-00

*The enclosed list with essential documents of the Technical Documentation forms a whole with this certificate. This certificate remains valid as long as the product is up to the assessed prototype and follows the instructions: Correct use of the certificate.*

*Thus made and drawn up at Joure, the Netherlands, in good faith  
and to the best of knowledge.*

*Certificate number:* DCI-ABYC-2112\*00  
*Date of issue:* 15-01-2019

Ms. A. Dijk  
Head of Certification

A blue ink signature, appearing to read 'A. Dijk', is written over the printed name and title.

## Annex A

### Essential Documents of the Technical Documentation

Date: 15-01-2019

Attachment of certificate: DCI-ABYC-2112\*00

#### Elucidation of the certificate:

The under mentioned essential documents of the Technical Documentation have been assessed for compliance with the essential safety requirements..

#### 1. Verification documents:

1.1 Technical file: 1551.18

#### 2. Test reports:

2.1 Static load test report: DCI  
Report number: 1551.18-RAP-01  
Report date: 15-01-2019

#### 3. Product identification:

The identification of the prototype are the drawings as stamped for approval by DCI on the 15<sup>th</sup> of January 2019

Ms. A. Dijk  
Head of Certification

Page 1 of 1

## EU Type – Examination Certificate



*Dutch Certification Institute, Notified Body for certification of Recreational Crafts to Directive 2013/53/EU (RCDII) under number 0613 and established at Joure, the Netherlands, herewith declares that the under mentioned product has been assessed according to module B of the Recreational Craft Directive 2013/53/EU and meets all applicable essential safety requirements.*

*Manufacturer:* Holland Marine Parts  
Donker Duyvisweg 297  
3316 BL Dordrecht  
The Netherlands

*Product description:* Composite Nozzles

*Types:* I-324-GF-00  
I-330-GF-00  
I-333-GF-00 / I-333-GF-SY-00  
I-336-GF-00 / I-336-GF-SY-00  
I-339-GF-00

*The enclosed list with essential documents of the Technical Documentation are integrated with this certificate. This certificate remains valid as long as the product is up to the assessed prototype and follows the instructions: Correct use of the certificate.*

*Thus made and drawn up at Joure, the Netherlands, in good faith  
and to the best of knowledge.*

*Certificate number:* DCI-CE-2013/53/EU-2112\*00  
*Date of issue:* 15-01-2019

*Ms. A. Dijk*  
*Head of Certification*



## Annex A

### Essential Documents of the Technical Documentation

Date: 15-01-2019

Attachment of certificate: DCI-CE-2013/53/EU-2112\*00

#### Elucidation of the certificate:

The under mentioned essential documents of the Technical Documentation have been assessed for compliance with the essential safety requirements regarding the design and construction for building of recreational crafts of Directive 2013/53/EU.

#### 1. Verification documents:

1.1 Technical file: 1551.18

#### 2. Test reports:

2.1 Test report: DCI  
Report number: 1551.18-RAP-01  
Report date: 15-01-2019

#### 3. Product identification:

3.1 The identification of the prototype are the drawings as stamped for approval by DCI on the 15<sup>th</sup> of January 2019

#### 4. Applied standards and documents:

RCD 2013/53/EU  
EN ISO 9093-2:2018

Ms. A. Dijk  
Head of Certification

Page 1 of 1

## Jet Thruster valve test rapport




### 3- way valve

serial number

V-100-58:

V-500-00:

V-200-50:

## Jet Thruster test rapport

Testdate:

HMP No:

JT-30-50:

JTV-30-50:

JT-50-50:

JTV-50-50:

JT-70-50:

JTV-70-50:

JT-90-50:

JTV-90-50:

OK:

Name :

Signature:




JT-30 / JT-50  
pos. 1

Serial No:




JT-30 / JT-50  
pos. 2

Serial No:



JT-70 / JT-90  
pos. 1

Serial No:




JT-70 / JT-90  
pos. 2

Serial No:



JT-30 / JT-50  
pos. 1

Serial No:



JT-70 / JT-90  
pos. 1

Serial No:

## Notes

---

# Project info

Owner: .....

Address: .....

Boat type: .....

Build by: .....

CIN code: .....

Date of installation: .....

Date of system activation: .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

Date OK: Name : Signature / stamp:

.....



**HOLLAND  
MARINE PARTS**

WE KEEP YOU MOVING!

## **GENERAL COMMERCIAL TERMS AND CONDITIONS**

General Commercial Terms and Conditions of  
**Holland Marine Parts B.V.**  
Donker Duyvisweg 297  
3316 BL Dordrecht  
The Netherlands

### **I Applicability of the Present General Terms and Conditions**

1. The present General Terms and Conditions shall apply to all offers and to all agreements concerning engines, machines and components. Unless the opposite appears explicitly, the present General Terms and Conditions shall equally apply to the assembly, disassembly, repair and other activities. The General Terms and Conditions of the customer shall not be binding on us, unless we have agreed to the contrary in writing.
2. The stipulations of the present General Terms and Conditions shall always remain in force, unless otherwise agreed upon in writing.
3. Each and every assignment or offer given orally or in writing by staff in the service of the contracting party, be they authorised to do so or not, on behalf of the contracting party, shall be binding on the contracting party. If the contracting party is not bound, then the party that concluded the agreement is deemed to be the contracting party.
4. In the present General Terms and Conditions "us" and "we" shall always refer to Holland Marine Parts B.V., whereas contracting party shall refer to our other party.
5. The nullity or annulity of any clause in the present General Terms and Conditions shall not prejudice the validity of the other clauses.

### **II Offer and Confirmation of the Order**

1. Our offers shall be without obligation in every respect, unless explicitly stated otherwise. We shall only be bound, having due regard to the stipulations hereinafter in the present General Terms and Conditions, when we have confirmed the order in writing. The same shall apply to potential additions and/or changes to the order.
2. The text of our order confirmation shall determine the contents of the order. Arrangements or agreements with employees shall not be binding on us, to the extent they have not been confirmed in writing by us.
3. All technical data can only be deemed to have been given to the contracting party as an approximation.
4. All drawings, illustrations, dimensions and weights given, shall remain our property under explicit reservation of copyrights and patent rights. Subject to our consent in writing, the contracting party shall not be allowed to copy said documents, to make them available for inspection to any third party or to make them otherwise available to any such third party. The contracting party shall hold us harmless against claims of third parties, including all extra judicial and judicial costs, that we have to make or pay to claimants, if the contracting party violates the provisions of this subsection.

### **III. Prices and Packaging**

1. Unless otherwise agreed upon in writing, prices shall be based on delivery at our enterprise in Dordrecht (ex Works).
2. The prices given, shall be exclusive of value added tax, unless stated otherwise.
3. If so required, packaging shall be charged at cost price and shall not be taken back. The decision as to the necessity to use packaging or not shall be made at our sole discretion.
4. If there are any changes in price, currency fluctuations, devaluation or revaluation of the Euro compared to any foreign currency or any changes to salaries, import duties or other taxes, social contributions or government levies, freight, etc., even if these changes occur due to circumstances that could already have been foreseen when the offer was made or accepted in writing, we shall be entitled to modify the sales prices and the costs for assembly, disassembly, repair and other costs, accordingly.



#### **IV Delivery and Delivery Period**

1. Goods shall be delivered at our enterprise in Dordrecht (ex Works). Delivery periods shall be determined approximately.
2. The delivery period shall commence when we have confirmed the order in writing, when all formalities required to start the activities have been complied with, when all necessary documents are in our possession and when the contracting party has provided us with all the data concerning the order. In the event of instalments, the delivery period shall only commence following receipt of the first instalment.
3. The delivery period shall be determined on the assumption that the necessary materials in the broadest sense of the word, be delivered to us in due time.
4. Exceeding the delivery period can never lead to any claim to damages, not even following a notice of default.
5. With respect to the delivery period, the goods shall be deemed to have been delivered when they are ready at our enterprise in Dordrecht and/or at the location referred to in our order confirmation and/or are made available at another location to be specified, all this after we have informed the contracting party thereof in writing. If we have accepted to assemble the goods, the goods shall be deemed to have been delivered in respect of the delivery period, when they have been made available at the place of delivery agreed upon.
6. From the moment the goods are deemed to have been delivered by virtue of section 5 of the present article, the risk of all direct and indirect damage to or in connection with said goods, sustained by the contracting party, shall be for the latter's account.

#### **V Transport**

1. From the moment they are shipped by or to us, all goods and materials shall be transported for the risk of the contracting party. Even in the case delivery carriage paid has been agreed upon, the contracting party shall be liable for all damage (such as damage caused by transport, fire and water, theft or embezzlement) to the goods during transport. The contracting party shall be under the obligation to take out an insurance to cover said risk, with the exclusion of recourse by the insurer(s) against us, our employees and/or supporting personnel.
2. The contracting party shall have to verify the condition the goods are in upon their arrival.
3. Without prejudice to the above, we shall not be liable for any damage whatsoever caused to the goods or not in connection with the transport.

#### **VI Assembly**

1. Unless otherwise agreed upon in writing, the assembly of the goods shall not be included in the delivery.
2. If an order to assemble the goods is given without a complete listing in writing of the activities the contracting party wants us to carry out, and if such activities are equally not referred to in the order confirmation, the agreement shall be deemed to include the activities we deem necessary.
3. The staff charged by us with the assembly, shall limit themselves to the assembly of the material supplied by us and/or the material that was included in the order. We shall not be responsible for assembly or repair work beyond the scope of the agreement or for any work done by third parties to materials, machines and/or machine components delivered by us.
4. When, through no fault of ours, the assembly work cannot be arranged for or done without interruption or is delayed in any other way, we shall be entitled to charge on the corresponding additional costs to the contracting party at the normal rate.
5. All potentially extra costs shall be for the account of the contracting party, more in particular:
  - a travel and accommodation expenses and cost of living of the technician(s);
  - b costs arising due to the fact that the assembly work cannot be done during usual day hours.
6. Upon completion of the assembly and when the goods have been put into operation, the assembly shall be deemed to have been carried out properly.
7. If the contracting party wishes to call on our services after assembly of the goods and after they have been put into operation or afterwards wishes to call in our assistance to inspect the goods sold / delivered, we shall be entitled to a reimbursement of expenses at the usual rate, to be increased by travel and accommodation expenses.

#### **VII Liability**

1. Neither we, nor our employees and/or our supporting personnel, shall be liable for any damage whatsoever, be it direct or indirect, regarding work done in the broadest sense of the word or regarding goods delivered pursuant to the agreements to which the present General Terms and Conditions apply.
2. Without prejudice to the stipulations of section 1, we shall only be liable for damage if the contracting party proves that the damage is due to gross negligence or intent on the part of the directors of Holland Marine Parts B.V.. We shall not indemnify the contracting party against gross negligence or intent on the part of our personnel or our supporting personnel, neither shall we indemnify the contracting party vis à vis any third party. Damage that has not been established by an expert appointed by us, shall never be considered to be damage. Under no circumstances shall we be liable for any kind of indirect damage whatsoever, no matter by whom such damage is sustained, including in particular consequential loss and/or the loss of time.
3. The contracting party shall be liable for all damage sustained by us or by our subordinates or supporting personnel, caused through the fault of the contracting party, including but not limited to, damage resulting from defects to or the nature of the goods delivered or made available by the contracting party, or otherwise due to circumstances which are reasonably for the risk of the contracting party.
4. The contracting party shall be under the obligation to state special characteristics or characteristics that pose a risk, of material made available by the contracting party, without such statement releasing the contracting party from the liability resulting from section 3 and the contracting party shall be under the obligation to indemnify us at its expense against all claims or titles of third parties and the consequences thereof, including measures to seize property before judgement.

5. The contracting party shall have to forthwith inform us of shortcomings or defects to repairs or deliveries that have been discovered, at any rate not later than three working days from the day the shortcoming or defect was discovered, and to do all that is necessary to limit the damage, all this under penalty of the loss of any right to damages or warranty.
6. If the contracting party wants to carry out an expert's appraisal (have such carried out), it shall have to inform us thereof in due time in order to enable the latter to be present, together with the latter's own experts or not, all this under penalty of the loss of any right to damages or warranty.
7. Notwithstanding any other provision, our liability shall never exceed a maximum of (25.000) twenty five thousand Euros.

#### **VIII Warranties**

1. Having due regard to the restrictions to be listed hereinafter, we shall undertake to repair or replace the new engines or machines we have delivered, which show a defect within a period of 24 months from the day of delivery as referred to in article IV, provided the defect is forthwith reported to us by telephone or in writing and provided that the defect is caused solely by faulty material or a faulty construction. The warranty shall not apply if the goods malfunction due to other causes such as normal wear and tear, unsuited kinds of fuel, lubricants, sealing and insulation material, measuring equipment, overloading, poor foundations, aggressive cooling water, faulty air supply, faulty piping, incorrect conduits, improper handling or accidents as well as in those cases in which the cause is not evident beyond doubt. The obligations under warranty do not comprise the burden to carry costs of cramage, electricity, docking, diving, dismounting, or travel and boarding costs.
2. With respect to the assembly, disassembly, repair and other work done by us, a warranty shall only be given for the reliability of the execution of the work done, unless explicitly otherwise agreed upon.
3. The obligations under the warranty shall lapse if the contracting party has made any changes or has done any repair work to the goods delivered on its own initiative during the term of warranty, or has had such done by a third party, or if, in our opinion, the contracting party has failed to properly service the goods delivered.
4. None of the indirect or direct damage, including consequential damage, sustained due to the malfunctioning of the goods delivered, shall be compensated.
5. We shall not be held to fulfil any obligation under the warranty if the contracting party fails to comply in a proper or timely manner with its obligation to pay or with any other obligation that might result from any agreement the contracting party has concluded with us.
6. No warranty shall be given for used engines, machines and components, unless explicitly agreed upon otherwise.
7. The warranty given on engines, machines and components purchased from third parties, shall not exceed the warranty given to us by our supplier(s).
8. The fact that obligations under the warranty may still exist on our part, shall not entitle the contracting party to postpone any payment, no matter what such payment is intended to cover.
9. Goods in respect of which warranty claims are lodged have to be shipped carriage paid. Components that are replaced shall become our property.
10. The warranty period in respect of goods which have been repaired or replaced under the warranty shall be three (3) months from the date of repair or replacement, or until the expiration date of the original warranty period of those goods.
11. All stipulations set out hereinabove and to be set out hereinafter, shall apply to the activities to be carried out by us under the present warranty clause. The warranty as set forth in this clause is the only warranty for the goods or services supplied, and replaces expressly any other warranty or claim, express or implied, whether in law or in contract. The contracting party waives all other further-reaching rights, whether from law or from contract.

#### **IX Conditions of Payment**

1. Payment of engines, machines, components, assembly, repairs and other activities shall have to be made in cash upon delivery, completion respectively, unless otherwise agreed upon in writing.
2. Delivery, completion respectively, as referred to in the first section of the present article, shall be understood to be:
  - a. with respect to engines and machines, the moment they are made available in our enterprise in Dordrecht and/or at the location stated in the order confirmation, or at another storage location of our choice to be specified;
  - b. with respect to components, the moment they leave our warehouses, or are kept ready in them for shipment respectively;
  - c. with respect to assembly and repairs, the moment the work is finished in our opinion;
  - d. expenses we advance that are for the account of the contracting party, shall be settled in conformity with the stipulations of section 1 of the present article.
3. We shall reserve the right to demand interim payments and/or, in our opinion, valid securities for the delivery of engines and/or machines as well as for assembly work, repairs and other services. The refusal on the part of the contracting party to furnish the security required, shall entitle us to dissolve the agreement by means of a written statement, without prejudice to our rights to compensation of expenses and loss of profits as well as of all other damage.
4. All payments shall have to be made without any deduction or set-off, either at our offices in Dordrecht, or by transfer into a bank account to be specified by us, unless explicitly otherwise agreed upon.
5. Complaints (each and every claim further to any alleged delivery deviating from the contract) concerning the execution of work or deliveries as well as invoices, shall have to be filed in writing by registered letter under penalty of nullity of the complaint concerned, within 8 days from completion or delivery of the work or the good concerned or from the day the invoices were sent. Complaints shall not suspend the contracting party's obligation(s) to pay.





6. If the contracting party is in default with the payment, it shall be deemed to be in default by operation of law and we shall have the right without any notice of default, to charge an interest on the entire amount due still outstanding, equalling the statutory commercial interest increased by 3% on an annual basis commencing on the date the payment concerned becomes due and payable, or, in the case of instalments, commencing on the day the term of the instalment concerned expires, and furthermore to recover all collection costs, both the judicial and extrajudicial costs, from the contracting party, all this without prejudice to the other rights vested in us. The extrajudicial collection costs shall amount to 15% of the principal with a minimum of EURO 250.-.
7. All of the delivered goods shall remain our property until they have been paid in full. As long as payment in full has not yet been made, the contracting party shall not be entitled without our consent in writing to that effect, to dispose of the goods in any way whatsoever. In order to be able to exercise our property rights, the contracting party shall be under the obligation if it wishes to establish any mortgage right, right of pledge or any other restricted right to any immovable property, registered good or movable property for which the goods to be delivered by us are intended, to first inform the creditor that the goods delivered are still our property and that a mortgage right, right of pledge or any other restricted right first requires our consent in writing.

#### **X Retention of Title**

1. Up to the moment the contracting party has paid our claim concerning the goods delivered and/or the work done in full, the goods delivered, be they processed or not, shall remain our exclusive property for the account and the risk of the contracting party.
2. The contracting party shall not be authorised to give said goods as collateral, to let them or to transfer title to them to any third party.
3. If goods are taken back, we shall reserve the right to claim all damage, loss of profits and interest.
4. The contracting party shall be under the obligation to forthwith notify us of the fact that third parties enforce rights to goods falling under the retention of title pursuant to the present article.
5. If it is shown at any point in time that the contracting party has failed to fulfil any of aforementioned obligations, the contracting party shall owe a penalty to the amount of 15% of the unpaid part of the purchase price or the work done, without prejudice to the right to damages.

#### **XI Dissolution / Cancellation**

1. Each and every failure to comply with any obligation on the part of the contracting party, shall entitle us to dissolve the agreement(s) by means of a mere written statement, without prejudice to our right to damages. At our own discretion, we shall always be able to demand compliance with the agreement(s), without prejudice to the right to damages. Failure to comply with any obligation shall also count as a resolatory condition which we can invoke in writing at our own discretion, without prejudice to our right to claim compensation for all damage.
2. The contracting party shall waive all rights to dissolution of the agreement, unless cancellation of the agreement in conformity with the stipulations of section 3 of the present article is agreed upon.
3. The contracting party shall only be able to cancel the agreement if we consent to it. In that event, the contracting party shall owe us a compensation to the amount of 15% of the contracting / purchase price (exclusive of VAT), unless the damage, which shall include the costs and the loss of profits, exceeds 15% of the contracting / purchase price (exclusive of VAT), in which case the compensation shall cover the total amount of damage, interest and costs. In the event the agreement is cancelled, the contracting party cannot lay claim to anything that we have already done and everything that we have already done shall have to be undone at the expense of the contracting party, all this at our discretion.

#### **XII Purchase Conditions**

1. If and in so far as we, as a buyer, are bound, the following conditions shall apply instead of the stipulations of III, IV, VI and VIII through X, maintaining the other stipulations:
2. Prices shall be fixed prices and delivery periods shall always be terms to be observed on penalty of forfeiture of rights, unless otherwise stated.
3. In the event of late delivery, the contracting party shall be immediately in default and shall always owe us a penalty to the amount of the purchase price agreed upon exclusive of VAT, without prejudice to the right to damages to the extent the latter exceed said penalty. The penalty and the damages can be settled against any sum we may owe under any agreement whatsoever.
4. The contracting party shall undertake to give the warranty we are held to give our customers.

#### **XIII Disputes**

All disputes between us and the contracting party resulting from any agreement, preliminary agreement or any other legal relationship whatsoever, shall be exclusively referred to the judgement of the competent court in Dordrecht, subject to the absolute competence of the subdistrict sector. The court in Dordrecht, division for interim injunction proceedings, shall be exclusively competent for interim injunctions.

#### **XIV Applicable Law**

Dutch law exclusively, shall apply to all offers made and agreements concluded on the present General Terms and Conditions and the consequences thereof. The application of the Vienna Sales Convention shall be excluded.



## Nozzle 0°

I-324-10 (JT-30 & JT-50)  
I-324-20 (JT-70 & JT-90)


# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

Nozzle 0°



- Nozzle must be 7-10 cm bellow waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



## Nozzle 25°


I-330-10 (JT-30 & JT-50)  
I-330-20 (JT-70 & JT-90)

# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

Nozzle 25°

- Nozzle must be 7-10 cm below waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



## Nozzle 35°


I-333-10 (JT-30 & JT-50)  
I-333-20 (JT-70 & JT-90)

# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

Nozzle 35°

- Nozzle must be 7-10 cm below waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



## Nozzle 35° SY


I-333-10 SY (JT-30 & JT-50)  
I-333-20 SY (JT-70 & JT-90)

# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

## Nozzle 35° SY

- Nozzle must be 7-10 cm below waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



## Nozzle 45°


I-336-10 (JT-30 & JT-50)  
I-336-20 (JT-70 & JT-90)

# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

Nozzle 45°

- Nozzle must be 7-10 cm bellow waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat





## Nozzle 45° SY

I-336-10 SY (JT-30 & JT-50)


I-336-20 SY (JT-70 & JT-90)

# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

## Nozzle 45° SY

- Nozzle must be 7-10 cm bellow waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



## Nozzle 55°

I-339-10 (JT-30 & JT-50)  
I-339-20 (JT-70 & JT-90)


# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

## Nozzle 55°



- Nozzle must be 7-10 cm below waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



## Nozzle 65°


I-341-10 (JT-30 & JT-50)  
I-341-20 (JT-70 & JT-90)

# BOAT HULL

### PRESS TO HULL TO DETERMINATE THE HULL ANGLE

#### Nozzle 65°

- Nozzle must be 7-10 cm below waterline
- Nozzle must be horizontal
- Nozzle must be perpendicular (90°) to centerline of the boat



---

CE

---



All our products are manufactured according to CE regulations.  
We keep the rights to change descriptions, graphs or statements,  
which are required for technical development of our Jet Thruster systems.



**HOLLAND  
MARINE PARTS**  
WE KEEP YOU MOVING!